

IMPORTANT!

IN ORDER TO PRESERVE THE APPEARANCE AND ENHANCE THE RESIDUAL VALUE OF YOUR TRIUMPH MOTORCYCLE, MANY COMPONENTS INCORPORATED IN ITS CONSTRUCTION REQUIRE CLEANING AND PROTECTION EACH TIME THE MOTORCYCLE IS USED. SUCH ITEMS INCLUDE:-

- UNTREATED ALUMINIUM ITEMS
- CHROME PLATED ITEMS
- EXHAUST SYSTEM
- WHEELS
- BOLTS, SCREWS ETC.
- ALL BODYWORK

IT IS ESSENTIAL THAT THE MOTORCYCLE IS CLEANED AND DRIED EACH TIME IT IS USED AS THE APPEARANCE OF THE MOTORCYCLE WILL RAPIDLY DETERIORATE IF CLEANING IS NEGLECTED. THIS IS PARTICULARLY IMPORTANT IF THE MOTORCYCLE IS USED IN INCLEMENT WEATHER CONDITIONS.

WARRANTY CLAIMS FOR COSMETIC DETERIORATION OF PARTS WILL NOT BE ALLOWED IF IT IS APPARENT THAT THIS IMPORTANT ADVICE HAS BEEN NEGLECTED.

FOR FURTHER INFORMATION ON CLEANING THE MOTORCYCLE, PLEASE REFER TO THE MAINTENANCE AND ADJUSTMENT SECTION OF THIS OWNER'S HANDBOOK.

REMARQUE IMPORTANTE!

POUR CONSERVER LA BELLE APPARENCE DE VOTRE MOTO TRIUMPH ET AMELIORER SA VALEUR A SA REVENTE, PLUSIEURS DE SES COMPOSANTS DOIVENT ETRE NETTOYES ET PROTEGES APRES CHAQUE UTILISATION DE LA MOTO. PARMIS CES COMPOSANTS, CITONS:-

- PIECES EN ALUMINIUM NON TRAITE
- COMPOSANTS CHROMES
- SYSTEME D'ECHAPPEMENT
- ROUES
- BOULONS, VIS, ETC.
- TOUTE LA CARROSSERIE

IL EST INDISPENSABLE DE NETTOYER LA MOTO ET DE LA SECHER APRES CHAQUE UTILISATION CAR SON APPARENCE SERA AFFECTEE SI ON NEGLIGE SON NETTOYAGE. CELA EST PARTICULIEREMENT IMPORTANT LORSQUE LA MOTO EST UTILISEE DANS DES CONDITIONS ATMOSPHERIQUES DEFAVORABLES.

LES REVDICATIONS SOUS GARANTIE CONCERNANT UNE DETERIORATION D'APPARENCE ESTHETIQUE DES PIECES SERONT REFUSEES S'IL EST EVIDENT QUE CES CONSEILS IMPORTANTS ONT ETE NEGLIGES.

PRIERE DE CONSULTER LA SECTION D'ENTRETIEN ET DE REGLAGE DE CE MANUEL DU CONDUCTEUR POUR TOUT COMPLEMENT D'INFORMATION CONCERNANT L'ENTRETIEN DE LA MOTO.

ACHTUNG!

ZUR BEWAHRUNG DER OPTIK IHRES TRIUMPH-MOTORRADES SOWIE SEINES RÜCKKAUFWERTES IST BEI ZAHLREICHEN TEILEN NACH JEDER FAHRT REINIGUNGS- UND KONSERVIERUNGSMASSNAHMEN DURCHZUFÜHREN:

- UNBEHANDELTE ALUMINIUMTEILE
- CHROMTEILE
- AUSPUFFANLAGE
- RÄDER
- SCHRAUBEN USW.
- ALLE KAROSSERIETEILE


ES IST WICHTIG, DAS MOTORRAD NACH JEDER FAHRT ZU REINIGEN UND ZU TROCKNEN. WIRD DIE REINIGUNG VERNACHLÄSSIGT, VERLIERT DAS FAHRZEUG SCHNELL AN OPTISCHEM WERT. DAS GILT BESONDERS FÜR FAHRTEN BEI SCHLECHTEM WETTER.

GEWÄHRLEISTUNGSANSPRÜCHE WEGEN MINDERUNG DES OPTISCHEN ERSCHEINUNGSBILDS VON TEILEN WERDEN NICHT ANERKANNT, SOFERN DIE ERFORDERLICHEN REINIGUNGSARBEITEN OFFENSICHTLICH NICHT REGELMÄSSIG DURCHFÜHRT WURDEN.

WEITERE HINWEISE ZUR REINIGUNG DES MOTORRADES SIND DEM ABSCHNITT WARTUNG UND EINSTELLUNGEN DER BEDIENUNGSANLEITUNG ZU ENTNEHMEN.

Foreword

This handbook contains information on the Triumph Daytona 650 motorcycle. Always store this owner's handbook with the motorcycle and refer to it for information whenever necessary.



WARNING, CAUTION AND NOTE

Throughout this owner's handbook particularly important information is presented in the following form:



WARNING: This warning symbol identifies special instructions or procedures which, if not correctly followed could result in personal injury, or loss of life.



CAUTION: This caution symbol identifies special instructions or procedures which, if not strictly observed, could result in damage to, or destruction of, equipment.

NOTE:

- This note symbol indicates points of particular interest for more efficient and convenient operation.

Foreword

WARNING LABELS

At certain areas of the motorcycle, the symbol (right) can be seen. The symbol means 'CAUTION: REFER TO THE HANDBOOK' and will be followed by a pictorial representation of the subject concerned.

Never attempt to ride the motorcycle or make any adjustments without reference to the relevant instructions contained in this handbook.

See pages 10 and 11 for the location of all labels bearing this symbol. Where necessary, this symbol will also appear on the pages containing the relevant information.



MAINTENANCE

To ensure a long, safe and trouble free life for your motorcycle, maintenance should always be carried out by an authorised Triumph dealer.

Only an authorised Triumph dealer will have the necessary knowledge, equipment and skills to maintain your Triumph motorcycle correctly.

To locate your nearest Triumph dealer, contact the Triumph web-site at www.triumph.co.uk or telephone the authorised distributor in your country. Their address is given in the service record book which accompanies this handbook.

NOISE CONTROL SYSTEM

Tampering With Noise Control System Prohibited

Owners are warned that the law may prohibit:

- (a) The removal or rendering inoperative by any person other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; and
- (b) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

INFORMATION

The information contained in this publication is based on the latest information available at the time of printing. Triumph reserves the right to make changes at any time without prior notice, or obligation.

Not to be reproduced wholly or in part without the written permission of Triumph Motorcycles Limited.

© 2004 Triumph Motorcycles Limited, Hinckley, Leicestershire, England.

Publication part number 3856101 issue 1.

Foreword

OWNER'S HANDBOOK

Thank you for choosing a Triumph motorcycle. This motorcycle is the product of Triumph's use of proven engineering, exhaustive testing, and continuous striving for superior reliability, safety and performance. Please read this owner's handbook before riding in order to become thoroughly familiar with the correct operation of your motorcycle's controls, its features, capabilities and limitations.

This handbook includes safe riding tips, but does not contain all the techniques and skills necessary to ride a motorcycle safely. Triumph strongly recommends that all riders undertake the necessary training to ensure safe operation of this motorcycle.



WARNING: This owner's handbook and all other instructions which are supplied with your motorcycle should be considered a permanent part of your motorcycle and should remain with it even if your motorcycle is subsequently sold.

All riders must read this owner's handbook and all other instructions which are supplied with your motorcycle before riding in order to become thoroughly familiar with the correct operation of your motorcycle's controls, its features, capabilities and limitations. Do not lend your motorcycle to others as riding when not familiar with your motorcycle's controls, features, capabilities and limitations can lead to an accident.

TABLE OF CONTENTS

This handbook contains a number of different sections. The table of contents below will help you find the beginning of each section where, in the case of the major sections, a further table of contents will help you find the specific subject required.

Foreword	1
Warning Labels	10
Parts Identification	12
Serial Numbers	15
General Information	17
How to Ride the Motorcycle	33
Accessories, Loading and Passengers	41
Maintenance and Adjustment	45
Storage	82
Specifications	83
Alphabetical Index	87

Foreword - Safety First

THE MOTORCYCLE



WARNING: This motorcycle is designed for on-road use only. It is not suitable for off-road use.

Off-road operation could lead to loss of control of the motorcycle resulting in an accident causing injury or loss of life.



WARNING: This motorcycle is not designed to tow a trailer or be fitted with a sidecar. Fitting a sidecar and/or a trailer may result in loss of control and an accident.



WARNING: This motorcycle is designed for use as a two-wheeled vehicle capable of carrying a rider on his own, or a rider and one passenger (subject to a passenger seat being fitted).

The total weight of the rider, and any passenger, accessories and luggage must not exceed the maximum load limit of 195 kg (429 lbs).

FUEL & EXHAUST FUMES



WARNING: PETROL IS HIGHLY FLAMMABLE:

Always turn off the engine when refuelling.

Do not refuel or open the fuel filler cap while smoking or in the vicinity of any open (naked) flame.

Take care not to spill any petrol on the engine, exhaust pipes or silencers when refuelling.

If petrol is swallowed, inhaled or allowed to get into the eyes, seek immediate medical attention.

Spillage on the skin should be immediately washed off with soap and water and clothing contaminated with petrol should immediately be removed.


Burns and other serious skin conditions may result from contact with petrol.




WARNING: Never start your engine or let it run for any length of time in a closed area. The exhaust fumes are poisonous and may cause loss of consciousness and death within a short time. Always operate your motorcycle in the open-air or in an area with adequate ventilation.

Foreword - Safety First

CRASH HELMET & CLOTHING

 **WARNING:** When riding the motorcycle both rider and passenger must always wear a crash helmet, eye protection, gloves, trousers (close fitting around the knee and ankle) and a brightly coloured jacket. Brightly coloured clothing will considerably increase a rider's (or passenger's) visibility to other operators of road vehicles. Although full protection is not possible, wearing correct protective clothing can reduce the risk of injury when riding.


 **WARNING:** A crash helmet is one of the most important pieces of riding gear as it offers protection against head injuries. You and your passenger's crash helmet should be carefully chosen and should fit you or your passenger's head comfortably and securely. A brightly coloured helmet will increase a rider's (or passenger's) visibility to other operators of road vehicles.

An open face helmet offers some protection in an accident though a full face helmet will offer more.


Always wear a visor or approved goggles to help vision and to protect your eyes.



HANDLEBARS & FOOTRESTS

 **WARNING:** The rider must maintain control of the vehicle by keeping hands on the handlebars at all times.

The handling and stability of a motorcycle will be adversely affected if the rider removes his hands from the handlebars, resulting in loss of control or an accident.

 **WARNING:** Footrests provided must always be used by rider and passenger during operation of the vehicle.

By using the footrests, both rider and passenger will reduce the risk of inadvertent contact with any motorcycle components and will also reduce the risk of injury from entrapment of clothing.

Foreword - Safety First

RIDING



WARNING: Never ride the motorcycle when fatigued or under the influence of alcohol or other drugs.

Riding when under the influence of alcohol or other drugs is illegal.

Riding when fatigued or under the influence of alcohol or other drugs reduces the rider's ability to maintain control of motorcycle and may lead to loss of control and an accident.



WARNING: All riders must be licensed to operate the motorcycle. Operation of the motorcycle without a licence is illegal and could lead to prosecution. In addition, operation without a licence is dangerous and may lead to loss of motorcycle control and an accident.



WARNING: Always ride defensively and wear the protective equipment mentioned elsewhere in this foreword. Remember, in an accident, a motorcycle does not give the same impact protection as a car.



WARNING: This Triumph motorcycle should be operated within the legal speed limits for the particular road travelled.

Operating a motorcycle at high speeds can be potentially dangerous since the time available to react to given traffic situations is greatly reduced as road speed increases.

Always reduce speed in potentially hazardous driving conditions such as bad weather or heavy traffic.



WARNING: Continually observe and react to changes in road surface, traffic and wind conditions. All two-wheeled vehicles are subject to external forces which may cause an accident. These forces include but are not limited to:

- Wind draft from passing vehicles.
- Uneven or holed road surfaces.
- Bad weather.
- Rider error.

Always operate the motorcycle at moderate speed and away from heavy traffic until you have become thoroughly familiar with its handling and operating characteristics. Never exceed the legal speed limit.

Foreword - Safety First

PARKING



WARNING: Always turn off the engine and remove the ignition key before leaving the motorcycle unattended. By removing the key, the risk of use of the motorcycle by unauthorised or untrained persons is reduced.

When parking the motorcycle, always remember the following:-

The engine and exhaust system will be hot after riding. **DO NOT** park where pedestrians, animals and/or children are likely to touch the motorcycle.

Do not park on soft ground or on a steeply inclined surface. Parking under these conditions may cause the motorcycle to fall over.

For further details, please refer to the 'How to Ride the Motorcycle' section of this owner's handbook.

PARTS & ACCESSORIES



WARNING: Owners should be aware that the only approved parts, accessories and conversions for any Triumph motorcycle are those which carry official Triumph approval and are fitted to the motorcycle by an authorised dealer.

Triumph does not accept any liability whatsoever for defects caused by the fitting of non-approved parts, accessories or conversions or the fitting of any approved parts, accessories or conversions by non-approved personnel.

In particular, it is extremely hazardous to fit or replace parts or accessories whose fitting requires the dismantling of, or addition to, either the electrical or fuel systems and any such modification could cause a safety hazard.

The fitting of any non-approved parts, accessories or conversions may adversely affect the handling, stability or other aspect of the motorcycle operation which may result in an accident causing injury or death.

Foreword - Safety First

MAINTENANCE & EQUIPMENT



WARNING: Consult your authorised Triumph dealer whenever there is doubt as to the correct or safe operation of this Triumph motorcycle.

Remember that continued operation of an incorrectly performing motorcycle may aggravate a fault and may also prejudice safety.



WARNING: Use of a motorcycle with bank angle indicators worn beyond the maximum limit (when 10 mm or more of the radiused tip of either front footrest is worn away) will allow the motorcycle to be banked to an unsafe angle.

Never change the setting of the brake pedal adjustment pushrod as this may adversely affect the bank angle at which the bank angle indicators contact the ground.

Banking to an unsafe angle may cause instability, loss of control and an accident causing injury or death.



WARNING: Ensure all equipment which is required by law is installed and functioning correctly.

The removal or alteration of the motorcycles lights, silencers, emission or noise control systems can violate the law.

Incorrect or improper modification may adversely affect the handling, stability or other aspect of the motorcycle operation which may result in an accident causing injury or death.



WARNING: If the motorcycle is involved in an accident or collision it must be taken to an authorised Triumph dealer for inspection and repair. Any accident can cause damage to the motorcycle which, if not correctly repaired, may cause a second accident which may result in injury or death.

Foreword - Safety First


This page is intentionally free from information.

Warning Labels

WARNING LABELS


Warning Label Locations - Daytona 650

The labels detailed on this and the following pages draw your attention to important safety information in this handbook. Before riding, ensure that all riders have understood and complied with all the information to which these labels relate.




Warning Labels

Warning Label Locations - Daytona 650 (continued)



Parts Identification


PARTS IDENTIFICATION - DAYTONA 650



- | | |
|---------------------|----------------------------|
| 1. Front Indicator | 9. Front Brake Disc |
| 2. Headlamp | 10. Front Brake Caliper |
| 3. Rear Lamp | 11. Fuel Tank |
| 4. Radiator | 12. Fuel Filler Cap |
| 5. Drive Chain | 13. Seat Lock |
| 6. Rear Indicator | 14. Coolant Expansion Tank |
| 7. Side Stand | 15. Coolant Pressure Cap |
| 8. Gearchange Pedal | 16. Battery (beneath seat) |

Parts Identification


PARTS IDENTIFICATION - DAYTONA 650 (continued)



- | | |
|--------------------------------|--|
| 17. Tool Kit | 23. Clutch Cable |
| 18. Rear Brake Disc | 24. Front Fork |
| 19. Rear Brake Caliper | 25. Rear Suspension Unit |
| 20. Rear Brake Fluid Reservoir | 26. Engine Management ECM (beneath seat) |
| 21. Rear Brake Pedal | 27. Silencer |
| 22. Oil Filler Plug/Dipstick | |


Parts Identification

PARTS IDENTIFICATION - DAYTONA 650 (continued)



- | | |
|--------------------------------|-------------------------------|
| 1. Clutch Lever | 9. Engine Stop Switch |
| 2. Passing Button | 10. Starter Button |
| 3. Headlamp Dipswitch | 11. Tachometer |
| 4. Horn Button | 12. Speedometer |
| 5. Indicator Switch | 13. Warning Lights |
| 6. Ignition Switch | 14. Low Fuel Warning |
| 7. Front Brake Fluid Reservoir | 15. Coolant Temperature Gauge |
| 8. Front Brake Lever | |


Serial Numbers



1. V.I.N. Number

Vehicle Identification Number (V.I.N.)

The vehicle identification number is stamped into the steering head. It is also displayed on a plate, riveted to the frame, immediately behind the steering head.



1. Engine Serial Number

Engine Serial Number

The engine serial number is stamped on the crankcase, immediately above the clutch cover.

Serial Numbers

This page is intentionally free from information.


General Information

Contents

Instruments	18
Warning Lights	21
Ignition Key	22
Ignition Switch/Steering Lock	22
Brake Lever Adjuster	23
Right Handlebar Switches	24
Left Handlebar Switches	25
Fuel Requirement	26
Fuel Tank Cap	27
Stand	28
Tool Kit	28
Handbook Storage	28
Seat Lock Operation/Seat Removal	29
Running-in	30
Safe Operation	31

General Information

INSTRUMENT PANEL LAYOUT



1. Tachometer
2. Tachometer 'Red Zone'
3. Speedometer
4. Odometer/Trip Meters/Clock Display
5. Select/Reset Buttons
6. Coolant Temperature Display
7. High Coolant Temperature/
Low Oil Pressure Warning Messages

SPEEDOMETER and ODOMETER

The digital speedometer indicates the road speed of the motorcycle. The read-out displays the motorcycle road speed in increments of one kilometer (or mile) per hour.

In the speedometer face is the electronic odometer, two trip meters and the clock. For details of the operation of the odometer, trip meters and clock, please refer to the following pages.

8. Engine Management Malfunction Indicator Light
9. Low Fuel Level Indicator Light
10. Neutral Indicator Light
11. High Beam Indicator Light
12. Low Oil Pressure/High Coolant Temperature Warning Light
13. Turn Indicator light


TACHOMETER

The tachometer shows the engine speed in revolutions per minute - rpm (r/min). On the right side of the tachometer face is the 'red zone'. Engine rpm (r/min) in the red zone is above maximum recommended engine speed and is also above the range for best performance.



CAUTION: Never allow engine RPM to enter the 'red zone' as severe engine damage may result.

General Information



1. Odometer Display
2. Trip Meter 1 Display
3. Trip Meter 2 Display
4. Select Button
5. Reset Button

ODOMETER/TRIP METER/CLOCK


The odometer shows the total distance that the motorcycle has travelled.

There are two trip meters. Either trip meter shows the distance that the motorcycle has travelled since the meter on display was last reset to zero. Also located in the same display frame is the clock.

To switch between the odometer, trip meter and clock display modes, press and release the left hand 'select' button. The display will scroll through in the order;

- odometer,
- trip meter 1,
- trip meter 2,
- clock.

To reset either of the trip meters to zero, select and display the trip meter to be zeroed and press the right hand 'reset' button to set the display to zero.



1. Clock Display
2. Hours Read-out
3. Minutes Read-out
4. Select Button
5. Reset Button

CLOCK ADJUSTMENT


To reset the clock, select the clock display and press both 'select' and 'reset' buttons together. After a short time, the clock's hour display will start to flash.

To reset the hour display, ensure that the hour display is still flashing then depress the 'reset' button to change the setting. Each individual press will change the setting by one digit. If the button is held, the display will continuously scroll through in single digit increments.

When the correct hour display is shown, press the 'select' button, the minutes display will begin to flash. The minutes display is adjusted in the same way as for hours.

Once both hours and minutes are correctly set, press the 'select' button to confirm the setting. The display will cease to flash.

General Information



1. Low Oil Pressure Display LOW OIL PRESSURE WARNING

If sufficient oil pressure is present, the display will not appear.


With the engine running, if the oil pressure becomes dangerously low, the low oil pressure symbol in the temperature display will flash. In addition, the low oil pressure warning light in the tachometer will illuminate.



CAUTION: Stop the engine immediately if the low oil pressure warning appears. Do not restart the engine until the fault has been rectified. Severe engine damage will result from running the engine when the low oil pressure warning light is illuminated

The low oil pressure symbol will flash and the low oil pressure warning in the tachometer will illuminate if the ignition is switched on without running the engine.

If the coolant temperature is below 40°C, the word 'LO' will also appear in the display. This does not indicate low oil pressure. It does, however, indicate that the coolant temperature is low.



1. Coolant Temperature Gauge COOLANT TEMPERATURE GAUGE

The coolant temperature gauge indicates the temperature of the engine coolant.

When the ignition is switched on, with the engine cold, the word 'LO' will be displayed indicating that the coolant is below 40°C (114°F). Once the coolant temperature rises above 40°C (114°F), the temperature in degrees will be displayed.

If the coolant temperature reaches 120°C (248°F) the high temperature warning in the temperature display, and the temperature read-out will both begin to flash. The warning light in the tachometer will also be illuminated.

If the coolant temperature reaches 129°C (266°F) the high temperature warning in the temperature display will flash and the flashing word 'HI' will appear in place of the temperature display. The warning light in the tachometer will also be illuminated.



CAUTION: Do not continue to run the engine if the high temperature warnings are displayed as severe engine damage may result.

General Information

WARNING LIGHTS



INDICATORS: When the indicator switch is turned to left or right, the corresponding direction indicator light flashes on and off.



HIGH BEAM: When the headlights are switched on and the headlight dip switch is set to 'high beam', the high beam warning light will illuminate.



LOW FUEL: The low fuel indicator will illuminate when there are approximately 5.0 litres of fuel remaining in the tank.



NEUTRAL: The neutral warning light indicates when the transmission is in neutral (no gear selected). The warning light will illuminate when the transmission is in neutral with ignition switch in the 'ON' position.



ENGINE MANAGEMENT SYSTEM MALFUNCTION INDICATOR LIGHT:


The malfunction indicator light for the engine management system illuminates when the ignition is switched on, remains illuminated during starting, and goes out shortly after the engine starts.

If the malfunction indicator light becomes illuminated during riding, a fault has occurred in the engine management system. In this case the system will switch to 'limp-home' mode so that riding may continue. Contact an authorised Triumph dealer as soon as possible to have the fault checked out and rectified.



WARNING: Do not continue to ride for a long period with the malfunction indicator light illuminated. The fault which has occurred may affect engine performance and fuel consumption. Reduced engine performance could cause a dangerous riding condition, leading to loss of control and an accident

General Information



1. Key Number Tag

IGNITION KEY


In addition to operating the steering lock/ignition switch, the ignition key is required to operate the seat lock and fuel tank cap.

When the motorcycle is delivered from the factory, two keys are supplied together with a small tag bearing the key number. Make a note of the key number and store the spare key and key number tag in a safe place away from the motorcycle.

Your authorised Triumph dealer can supply a replacement key cut from details of the key number or can cut a new key using the original as a master.



CAUTION: Do not store the spare key with the motorcycle as this will reduce all aspects of security.



1. Ignition Switch/Steering Lock
2. LOCK position
3. OFF position
4. ON position
5. P (Park) position

IGNITION SWITCH/STEERING LOCK

This is a four position, key operated switch. The key can be removed from the switch only when it is in the OFF, LOCK or P (PARK) position.

TO LOCK: Turn the key to the 'OFF' position, push and fully release the key, then rotate it to the 'LOCK' position.





'PARKING': Turn the key from the 'LOCK' position to the 'P' position. The steering remains locked.


NOTE:

- Do not leave the steering lock in the 'P' position for long periods as this will cause the battery to discharge.


General Information

Ignition Switch Positions


	Engine off. All electrical circuits off.
	Engine on. All electrical equipment can be used.
	Steering locked. Engine off. All electrical circuits off.
	Steering locked. Engine off. Position and licence plate lights on, all other electrical circuits cut off.

 **WARNING:** For reasons of security and safety, always turn the ignition to 'OFF' and remove the key when leaving the motorcycle unattended.

Any unauthorised use of the motorcycle may cause injury to the user, other road users and pedestrians and may also cause damage to the motorcycle.

 **WARNING:** With the key in the 'LOCK' or 'P' position the steering will become locked.

Never turn the key to 'Lock' or 'P' while the motorcycle is moving as the steering will lock. Locked steering will cause loss of control and an accident.




1. Lever Adjuster Wheel
2. Triangular Reference Mark

BRAKE LEVER ADJUSTER

An adjuster is fitted to the front brake lever. The adjuster allows the distance from the handlebar to the brake lever to be changed to one of four positions, to suit the span of the operator's hands.


To adjust the lever, push the lever forward and turn the adjuster wheel to align one of the numbered positions with the triangular mark on the lever holder.

The distance from the hand grip to the released lever is shortest when set to number four and longest when set to number one.

 **WARNING:** Do not attempt to adjust the brake lever with the motorcycle in motion as this may lead to loss of control and an accident.

After adjusting the lever, operate the motorcycle in an area free from traffic to gain familiarity with the new lever setting. Do not loan your motorcycle to anyone as they may change the lever setting from the one you are familiar with causing loss of control or an accident.

General Information





1. Engine Stop Switch
2. Starter Button

RIGHT HANDLEBAR SWITCHES



Engine Stop Switch

In addition to the ignition switch being turned to the 'ON' position, the engine stop switch must be in the  position for the motorcycle to operate.

The engine stop switch is for emergency use. If an emergency arises which requires the engine to be stopped, move the engine stop switch to the  position.

NOTE:

- Although the engine stop switch stops the engine, it does not turn off all the electrical circuits and may cause difficulty in restarting the engine. Ordinarily, only the ignition switch should be used to stop the engine.



CAUTION: Do not leave the ignition switch in the 'ON' position unless the engine is running as this may cause damage to electrical components and the battery.




Starter Button

The starter button operates the electric starter. For the starter to operate, the transmission must be in neutral and the clutch lever pulled to the handlebar.

NOTE:

- Even if the clutch lever is pulled in, the starter will not operate if the side stand is down and a gear is engaged.

General Information



1. Headlight Dip Switch
2. Direction Indicator Switch
3. Horn Button
4. Passing Button

LEFT HANDLEBAR SWITCHES





Headlight Dip Switch

High or low beam can be selected with the headlight dip switch. To select high beam, push the switch forward. To select low beam, push the switch rearwards. When the high beam is turned on, the high beam warning light will illuminate.



Direction Indicator Switch

When the indicator switch is pushed to  (left) or  (right) and released, the corresponding indicator flashes. To turn off the indicators, push and release the switch.



Horn Button

When the horn button is pushed, with the ignition switch turned to the 'ON' position, the horn will sound.



Pass Button

When the pass button is pressed, the headlight main beam will be switched on. It will remain on as long as the button is held in and will turn off as soon as the button is released.

NOTE:

- No light switch is fitted to this model as the headlight, rear light and licence plate light all function automatically when the ignition is turned to the ON position.

General Information

FUEL REQUIREMENT



Your Triumph engine is designed to use unleaded fuel and will give optimum performance if the correct grade of fuel is used. Always use unleaded fuel with an octane rating of 95 RON.



CAUTION: In many countries, the exhaust systems for this model is fitted with catalytic converters to help reduce exhaust emission levels. The catalytic converters can be permanently damaged if the motorcycle is allowed to run out of fuel or if the fuel level is allowed to get very low. Always ensure you have adequate fuel for your journey.



CAUTION: The use of leaded petrol is illegal in some countries, states or territories. Use of leaded fuel will damage the catalytic converter.

REFUELLING



WARNING: To help reduce hazards associated with fuel handling, always observe the following fuel safety instructions:

Petrol (fuel) is highly flammable and can be explosive under certain conditions. When refuelling, turn the ignition switch to the 'OFF' position.

Do not smoke.


Make sure the refuelling area is well ventilated and free from any source of flame or sparks. This includes any appliance with a pilot light.

Never fill the tank until the fuel level rises into the filler neck. Heat from sunlight or other sources may cause the fuel to expand and overflow creating a fire hazard.

After refuelling always check that the fuel filler cap is correctly closed and locked.

Because petrol (fuel) is highly flammable, any fuel leak or spillage, or any failure to observe the safety advice given above will lead to a fire hazard which could cause damage to property, injury to persons or death.

General Information



1. Ignition Switch Key
2. Fuel Tank Cap

Fuel Tank Cap

To open the fuel tank cap, lift up the key hole cover. Insert the key into the lock and turn the key clockwise. To close and lock the cap, push the cap down into place with the key inserted, until the lock 'clicks' into place. Withdraw the key and close the key cover.



CAUTION: Closing the cap without the key inserted will damage the cap, tank and lock mechanism.


Filling the Fuel Tank

Avoid filling the tank in rainy or dusty conditions where airborne material can contaminate the fuel.



CAUTION: Contaminated fuel may cause damage to fuel system components.

Fill the fuel tank slowly to help prevent spillage. Do not fill the tank to a level above the bottom of the filler neck. After refuelling always check that the fuel filler cap is correctly closed and locked. This will ensure there is enough air space to allow for fuel expansion if the fuel inside the



1. Fuel level
2. Filler neck
3. Air space

tank expands through absorption of heat from the engine or from direct sunlight.



WARNING: Overfilling the tank can lead to fuel spillage.


If petrol (fuel) is spilled, thoroughly wipe off the spilled fuel immediately and dispose of the cleaning cloth safely.

Take care not to spill any petrol (fuel) on the engine, exhaust pipes, tyres or any other part of the motorcycle.

Because petrol (fuel) is highly flammable, any fuel leak or spillage, or any failure to observe the safety advice given above will lead to a fire hazard which could cause damage to property, injury to persons or death.

Petrol (fuel) spilled near to or on the tyres will reduce the tyre's ability to grip the road. This will give rise to a dangerous riding condition causing loss of motorcycle control and an accident.

General Information



1. Side Stand

STAND

Side Stand

The motorcycle is equipped with a side stand on which the motorcycle can be parked. Whenever the stand is used, before riding, always ensure that the stand is fully up after first sitting on the motorcycle.

For instructions on safe parking, refer to the 'How to Ride the Motorcycle' section




WARNING: The motorcycle is fitted with an interlock system to prevent it from being ridden with the sidestand in the down position.

Never attempt to ride with the sidestand down or interfere with the interlock mechanism as this will cause a dangerous riding condition leading to loss of motorcycle control and an accident.

NOTE:

- When using the side stand, always turn the handlebars fully to the left and leave the motorcycle in first gear.



1. Handbook Location


TOOL KIT

The tool kit is strapped into a recess beneath the seat.

HANDBOOK STORAGE

To gain access to the handbook, remove the rear seat (as described elsewhere in this section). The handbook is located in a recess in the rear mudguard.

General Information



1. Front Seat Fixing Locations

SEAT LOCK


NOTE:

- **When delivered from the factory, the motorcycle is supplied with a rear seat and a rear cover. Either of these separate parts may be fitted according to rider preference. The process for removal and fitment of either the seat or cover is the same.**

Two seats, or a rider seat and rear cover can be fitted to this motorcycle. Both can be removed independently.

To remove the rider seat, gently push forward on the rear of the seat pad in order to expose the two seat fixings. Release the fixings, lift the rear of the seat and slide it rearwards to release it from the frame.

The rear seat/cover is secured by a key-operated lock which is situated on the left hand side of the motorcycle. To remove the rear seat/cover, insert the ignition key into the seat lock and turn the key anti-clockwise while pressing down on the rear part of the seat/cover.



1. Rear seat/cover lock

To detach the rear seat/cover, lift the rear of the seat/cover and slide it rearwards.

To refit the rider seat, engage the front section of the seat to the fuel tank and secure the rear with the two fixings. Tighten the fixings to **9 Nm**.

To refit the rear seat/cover, engage the front section of the seat to the front of the space provided and press down on the rear to engage in the seat lock.

NOTE:

- **An audible 'click' can be heard when the rear seat/cover is correctly engaged in the lock.**

! WARNING: To prevent detachment of the rear seat/cover during riding, after fitting always grasp the seat/cover and pull firmly upwards. If the seat/cover is correctly secured in the lock, it will not detach from the rear frame.

A loose or detached seat could cause loss of motorcycle control and an accident

General Information

RUNNING IN



Running-in is the name given to the process that occurs during the first hours of a new vehicle's operation.

In particular, internal friction in the engine will be higher when components are new. Later on, when continued operation of the engine has ensured that the components have 'bedded in', this internal friction will be greatly reduced.

A period of careful running in will ensure lower exhaust emissions, and will optimise performance, fuel economy and longevity of the engine and other motorcycle components.

During the first 500 miles (800 kilometres):-

- Do not use full throttle.
- Avoid high engine speeds at all times.
- Avoid riding at one constant engine speed, whether fast or slow, for a long period of time.
- Avoid aggressive starts, stops, and rapid accelerations, except in an emergency.
- Do not ride at speeds greater than 3/4 of maximum speed.

From 500 to 1000 miles (800 to 1500 kilometres):-

- Engine speed can gradually be increased to the rev limit for short periods.

Both during and after running in has been completed:-

- Do not over-rev the engine when cold.
- Do not let the engine labour. Always downshift before the engine begins to 'struggle'.
- Do not ride with engine speeds unnecessarily high. Changing up a gear helps reduce fuel consumption, reduces noise and helps to protect the environment.

General Information


SAFE OPERATION

Daily Safety Checks

Check the following items each day before you ride. The time required is minimal, and these checks will help ensure a safe, reliable ride.

 	DAILY SAFETY CHECKS TÄGLICHE SICHERHEITSKONTROLLEN CONTROLES DE SECURITE QUOTIDIENS CHEQUEOS DE SEGURIDAD DIARIOS VERIFICAÇÕES DIÁRIAS DE SEGURANÇA VERIFICHE GIORNALIERE DI SICUREZZA DAGELIJSKE VEILIGHEIDSINSPECTIES
--	---

If any irregularities are found during these checks, refer to the Maintenance and Adjustment section or see your authorised Triumph dealer for the action required to return the motorcycle to a safe operating condition.

	WARNING: Failure to perform these checks every day before you ride may result in serious motorcycle damage or an accident causing serious injury or death.
--	---

Check:-

- **Fuel** Adequate supply in tank, no fuel leaks (Page 26).
- **Engine oil** Correct level on dipstick. Add correct specification oil as required. No leaks from the engine or oil cooler (Page 49).
- **Tyres/Wheels** Correct inflation pressures (when cold) (Page 69).
Tread depth/wear (min 2.0 mm tread depth), tyre/wheel damage, punctures etc.
- **Drive chain** Check drive chain for correct adjustment (Page 57).
- **Nuts, bolts, fasteners** Check that steering and suspension components, axles, and all controls are properly tightened or fastened. Visually inspect all areas for loose/damaged fixings.
- **Steering** Action smooth but not loose from lock to lock. No binding of any of the control cables (Page 63).
- **Brakes** Brake pad wear: There should be more than 1.5 mm lining remaining on all the pads. No brake fluid leakage. Brake fluid levels must be between max and min (Page 60).
- **Front Forks** Smooth action. No fork oil leakage (Page 65).
- **Throttle** Throttle grip play 2-3 mm. Ensure that the throttle grip returns to the idle position without sticking (Page 54).
- **Clutch** Smooth operation and correct cable free-play (Page 56).

General Information


- **Coolant** No coolant leakage. Check the coolant level in the expansion tank (when the engine is cold) (Page 51).
- **Electrical equipment** All lights and horn function correctly (Page 22).
- **Engine stop** Stop switch turns the engine off (Page 24 & 34).
- **Stands** Return to the fully up position by spring tension. Return springs not weak or damaged (Page 28).

How to Ride the Motorcycle

Contents

To Stop the Engine	34
To Start The Engine	34
Moving Off	35
Changing Gears	35
Braking	36
Parking	38
Considerations For High Speed Operation	39
Accessories, Loading and Passengers	41

How to Ride the Motorcycle



1. Engine Stop Switch
2. Starter Button
3. Neutral Indicator Light
4. On Position
5. Ignition Switch
6. Tachometer

TO STOP THE ENGINE

- Support the motorcycle on a firm, level surface with the side stand.
- Close the throttle completely.
- Select neutral.
- Turn the ignition switch off.
- Lock the steering.

CAUTION: The engine should normally be stopped by turning the ignition switch off. The engine stop switch is for emergency use only. Do not leave the ignition switched on with the engine stopped. Electrical damage may result.

TO START THE ENGINE

- Check that the engine stop switch is in the run position.

- Ensure that the transmission is in neutral.
- Pull the clutch lever fully in to the handlebar.
- Turn the ignition switch on.
- The tachometer needle will sweep from zero to maximum engine speed and then return to zero. When it returns to zero, leaving the throttle completely closed, push the starter button until the engine starts.

NOTE:

- **The starter will not operate until the tachometer needle reaches zero.**

WARNING: Never start the engine or run the engine in a confined area. Exhaust fumes are poisonous and can rapidly cause loss of consciousness and death within a short time.

Always operate your motorcycle in the open-air or in an area with adequate ventilation.

How to Ride the Motorcycle



CAUTION: Do not operate the starter continuously for more than 5 seconds as the starter motor will overheat and battery power will drop. Wait 15 seconds between each operation of the starter to allow for cooling and recovery of battery power.

Do not let the engine idle for long periods as this may lead to overheating which will cause damage to the engine.



CAUTION: The low oil pressure warning light should go out as soon as the engine starts.

If the low oil pressure warning light stays on after starting the engine, stop the engine immediately and investigate the cause.


Running the engine with low oil pressure will cause severe engine damage.

MOVING OFF

- Pull in the clutch lever and select first gear. Open the throttle slightly and let out the clutch lever slowly. As the clutch starts to engage, open the throttle a little more, allowing enough engine speed to avoid stalling.

CHANGING GEARS

- Close the throttle while pulling in the clutch lever. Change into the next higher or lower gear. Open the throttle part way, while releasing the clutch lever. Always use the clutch when changing gear.



1. Gear Change Pedal



WARNING: Take care to avoid opening the throttle too far in any of lower gears as this can lead to the front wheel lifting from the ground (pulling a 'wheelie') and the rear wheel breaking traction (wheel spin).

Always open the throttle cautiously, particularly if you are unfamiliar with the motorcycle, as a 'wheelie' will cause loss of motorcycle control and an accident.


NOTE:

- The gear change mechanism is the 'positive stop' type. This means that, for each movement of the gear change pedal, you can only select each gear, one after the other, in ascending or descending order.




WARNING: Do not change to a lower gear at speeds which will cause excessive engine rpm (r/min). This can lock the rear wheel causing loss of control and an accident. Engine damage may also be caused. Changing down should be done below 5000 rpm (r/min) for each gear.

How to Ride the Motorcycle



1. Front Brake Lever



1. Rear Brake Pedal

BRAKING



WARNING: WHEN BRAKING, OBSERVE THE FOLLOWING:

Close the throttle completely, leaving the clutch engaged to allow the engine to help slow down the motorcycle.

Change down one gear at a time such that the transmission is in first gear when the motorcycle comes to a complete stop.

When stopping, always apply both brakes at the same time. Normally the front brake should be applied a little more than the rear.

Change down or fully disengage the clutch as necessary to keep the engine from stalling.

Never lock the brakes, as this may cause loss of control of the motorcycle and an accident.



WARNING: For emergency braking, disregard down changing, and concentrate on applying the front and rear brakes as hard as possible without skidding. Riders should practice emergency braking in a traffic-free area.

Triumph strongly recommend that all riders take a course of instruction which includes advice on safe brake operation. Incorrect brake technique could result in loss of control and an accident.

How to Ride the Motorcycle



WARNING: For your safety, always exercise extreme caution when braking, accelerating or turning as any incautious action can cause loss of control and an accident. Independent use of the front or rear brakes reduces overall braking performance. Extreme braking may cause either wheel to lock, reducing control of the motorcycle and causing an accident.

When possible, reduce speed or brake before entering a turn as closing the throttle or braking in mid-turn may cause wheel slip leading to loss of control and an accident.

When riding in wet or rainy conditions, or on loose surfaces, the ability to manoeuvre and stop will be reduced. All of your actions should be smooth under these conditions. Sudden acceleration, braking or turning may cause loss of control and an accident.




WARNING: When descending a long, steep gradient use engine braking by down-changing and use the brakes intermittently. Continuous brake application can overheat the brakes and reduce their effectiveness.

Riding with your foot on the brake pedal or your hands on the brake lever may actuate the brake light, giving a false indication to other drivers. It may also overheat the brake, reducing braking effectiveness.

Do not coast with the engine switched off, and do not tow the motorcycle. The transmission is pressure-lubricated only when the engine is running. Inadequate lubrication may cause damage or seizure of the transmission which can lead to sudden loss of motorcycle control and an accident.

How to Ride the Motorcycle



PARKING

When parking the motorcycle, observe the following:

Select neutral and turn the ignition switch to the 'OFF' position. Lock the steering to help prevent theft.

Always park on a firm, level surface to prevent the motorcycle from falling.

When parking on a hill, always park facing uphill to prevent the motorcycle from rolling off the stand.

On a lateral (sideways) incline, always park such that the incline naturally pushes the motorcycle towards the sidestand.

Do not park on a lateral (sideways) incline of greater than 6° and never park facing downhill.

NOTE:

- **When parking near traffic at night, leave the licence plate and position lights on by turning the ignition switch to P (Park).**
- **Do not leave the switch in the 'P' position for long periods as this will discharge the battery.**



WARNING: Do not park on a soft or on a steeply inclined surface as parking under these conditions may cause the motorcycle to fall over.

Ensure that the stand is fully retracted before riding off.

Petrol is extremely flammable and can be explosive under certain conditions. If parking inside a garage or other structure, be sure it is well ventilated and the motorcycle is not close to any source of flame or sparks. This includes any appliance with a pilot light.

The engine and exhaust system will be hot after riding. **DO NOT** park where pedestrians and children are likely to touch the motorcycle as touching any of the hot parts may cause unprotected skin to become burnt.

How to Ride the Motorcycle

CONSIDERATIONS FOR HIGH SPEED OPERATION



WARNING: This Triumph motorcycle should be operated within the legal speed limits for the particular road travelled. Operating a motorcycle at high speeds can be potentially dangerous since the time available to react to given traffic situations is greatly reduced as road speed increases. Always reduce speed in consideration of weather and traffic conditions.



WARNING: Only operate this Triumph motorcycle at high speed in closed-course on-road competition or on closed course race tracks. High speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high speed riding and are familiar with the motorcycle's characteristics in all conditions.

High speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.



WARNING: The items listed are extremely important and must never be neglected. A problem which may not be noticed at normal operating speeds may be greatly exaggerated at high speeds.



WARNING: The handling characteristics of a motorcycle at high speed may vary from those you are familiar with at legal road speeds. Do not attempt high speed operation unless you have received sufficient training and have the required skills as a serious accident may result from incorrect operation.

Steering

Check that the handlebar turns smoothly without excessive free play or tight spots. Ensure that the control cables do not restrict the steering in any way.

Luggage:

Make certain that any luggage containers are closed, locked and securely fitted to the motorcycle.

Brakes

Check that the front and rear brakes are functioning properly.

Tyres

High speed operation is hard on tyres, and good tyres are crucial for riding safely. Examine their overall condition, inflate to the correct pressure (when the tyres are cold), and check the wheel balance. Securely fit the valve caps after checking tyre pressures. Observe the information given in maintenance and specification sections on tyre checking and tyre safety.

How to Ride the Motorcycle

Fuel

Have sufficient fuel for the increased fuel consumption that will result from high speed operation.

Engine Oil

Make certain that the oil level is correct. Ensure that the correct grade and type of oil is used when topping-up.

Coolant

Check that the coolant level is at the upper level line in the expansion tank. (Always check the level with the engine cold).

Electrical Equipment

Make certain that the headlight, rear/brake light, turn signals, horn etc., all work properly.

Miscellaneous

Make certain that all fixings are tight and that all safety related parts are in good condition.

Accessories, Loading and Passengers

The addition of accessories and carriage of additional weight can affect the motorcycle's handling characteristics causing changes in stability and necessitating a reduction in speed. The following information has been prepared as a guide to the potential hazards of adding accessories to a motorcycle and carrying passengers and additional loads.



WARNING: Incorrect loading may result in an unsafe riding condition leading to an accident.

Always ensure any loads carried are evenly distributed on both sides of the motorcycle. Ensure that the load is correctly secured such that it will not move around while the motorcycle is in motion.

Always check the load security regularly (though not while the motorcycle is in motion) and ensure that the load does not extend beyond the rear of the motorcycle.

Never exceed the maximum vehicle loading weight of 195 Kg (429 lbs).

This maximum weight is made up from the combined weight of the rider, passenger and any load carried.



WARNING: Do not install accessories or carry luggage that impairs the control of the motorcycle. Make sure that you have not adversely affected any lighting component, road clearance, banking capability (i.e. lean angle), control operation, wheel travel, front fork movement, visibility in any direction, or any other aspect of the motorcycle's operation.



WARNING: Never ride an accessory equipped motorcycle at speeds above 80 mph (130 km/h).

Speeds in excess of 130 km/h (80 mph) should not be attempted on an accessory equipped motorcycle even where the legal speed limit permits this.

The presence of accessories will cause changes in the stability and handling of the motorcycle.

Failure to allow for changes in motorcycle stability may lead to loss of control or an accident.

Remember that the 130km/h (80mph) absolute limit will be reduced by the fitting of non-approved accessories, incorrect loading, worn tyres, overall motorcycle condition and poor road or weather conditions.



WARNING: This motorcycle must not be operated above the legal road speed limit except in authorised closed course conditions.



WARNING: Only operate this Triumph motorcycle at high speed in closed-course on-road competition or on closed course race tracks. High speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high speed riding and are familiar with the motorcycle's characteristics in all conditions. High speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.

Accessories, Loading and Passengers

! WARNING: The handling and braking capabilities of a motorcycle will be affected by the presence of a passenger. The rider must make allowances for these changes when operating the motorcycle with a passenger and should not attempt such operation unless trained to do so and without becoming familiar and comfortable with the changes in motorcycle operating characteristics that this brings about.

Motorcycle operation without making allowances for the presence of a passenger could lead to loss of motorcycle control and an accident.

! WARNING: Your passenger should be thoroughly familiar with motorcycle operation.

The passenger can cause loss of control of the motorcycle by incorrect positioning during cornering and sudden movements.

It is important that the passenger sits still while the motorcycle is in motion and does not interfere with the operation of the motorcycle.

If a passenger is carried, the rider should instruct the passenger to keep his or her feet on the passenger footrests and to firmly hold onto the seat strap or the rider's waist or hips.

The passenger should also be advised to lean with the rider when travelling in corners and not to lean unless the rider does so.


Do not carry animals on your motorcycle.

! WARNING: Do not carry a passenger unless he or she is tall enough to reach the footrests provided.

A passenger who is not tall enough to reach the footrests will be unable to sit securely on the motorcycle and may cause instability leading to loss of control and an accident.

! WARNING: Never attempt to store any items between the frame and the fairing. This can restrict the steering and will cause loss of control leading to an accident.

Weight attached to the handlebar or front fork will increase the mass of the steering assembly and can result in loss of steering control leading to an accident.



! WARNING: If the passenger seat is used to carry small objects, they must not exceed 5kg in weight, must not impair control of the motorcycle, must be securely attached and must not extend beyond the rear and sides of the motorcycle.

Carriage of objects in excess of 5kg in weight, that are insecure, impair control or extend beyond the rear and sides of the motorcycle may lead to loss of motorcycle control and an accident

Accessories, Loading and Passengers

This page is intentionally free from information.

Maintenance and Adjustment



Your Triumph Motorcycle is a quality engineered product which has been carefully built and tested to exacting standards. Triumph Motorcycles are keen to ensure that you enjoy optimum performance from your machine and with this objective in mind have tested many of the engine lubricants currently available to the limits of their performance.

Mobil 1 Racing 4T consistently performed well during our tests and has become our primary recommendation for the lubrication of all current Triumph motorcycle engines.

Mobil 1 Racing 4T, specially filled for Triumph, is available from your authorised Triumph dealer.

Maintenance and Adjustment

Contents

Scheduled Maintenance	46
Side Panel	48
Engine Oil	49
Cooling System	51
Throttle Grip	54
Clutch	56
Drive Chain	57
Brakes	60
Steering/Wheel Bearings	63
Windscreen Cleaning	63
Front Suspension	65
Suspension Adjustment	65
Tyres	69
Battery	73
Fuses	75
Headlights	77
Rear Light	79
Indicator Light	79
Cleaning	80
Storage	82

Maintenance and Adjustment

SCHEDULED MAINTENANCE

To maintain the motorcycle in a safe and reliable condition, the maintenance and adjustments outlined in this section must be carried out as specified in the schedule of daily checks, and also in line with the scheduled maintenance chart. The information which follows describes the procedures to follow when carrying out the daily checks and some simple maintenance and adjustment items.



WARNING: In order to correctly carry out the maintenance items listed in the scheduled maintenance chart, special tools and specialist knowledge will be required. Only an authorised Triumph dealer will have this knowledge and equipment.

Since incorrect or neglected maintenance can lead to a dangerous riding condition, always have an authorised Triumph dealer carry out the scheduled maintenance of this motorcycle.

Scheduled Maintenance Chart						
Operation Description	Odometer Reading in Miles (Kms) or time period, whichever comes first.					
	Every	500 (800) 1 month	6000 (10000) 1 year	12000 (20000) 2 years	18000 (30000) 3 years	24000 (40000) 4 years
Engine/oil cooler - check for leaks	Day	●	●	●	●	●
Engine oil - renew	-	●	●	●	●	●
Engine oil filter - renew	-	●	●	●	●	●
Valve clearances - check/adjust	-			●		●
Air cleaner element - renew	-			●		●
Engine ECM - check for stored DTCs	-	●	●	●	●	●
Spark plugs - check	-		●		●	
Spark plugs - renew	-			●		●
Throttle bodies - balance	-		●	●	●	●
Throttle cable - check/adjust	Day	●	●	●	●	●
Coolant level - check/adjust	Day	●	●	●	●	●
Coolant - renew	Every 2 Years					
Cooling system - check for leaks	Day	●	●	●	●	●
Fuel system - check for leaks	Day	●	●	●	●	●
Lights, instruments & electrical systems - check	Day	●	●	●	●	●

Maintenance and Adjustment

Scheduled Maintenance Chart (Continued)						
Operation Description	Odometer Reading in Miles (Kms) or time period, whichever comes first.					
	Every	500 (800) 1 month	6000 (10000) 1 year	12000 (20000) 2 years	18000 (30000) 3 years	24000 (40000) 4 years
Fuel Filter - renew	-			●		●
Steering - check for free operation	Day	●	●	●	●	●
Headstock bearing - check/adjust	-		●	●	●	●
Headstock bearing - lubricate	-			●		●
Forks - check for leaks/smooth operation	Day	●	●	●	●	●
Fork oil - renew	-					●
Brake fluid levels - check	Day	●	●	●	●	●
Brake fluid - renew	Every 2 years					
Brake pads - check wear levels	Day	●	●	●	●	●
Brake calipers - check for leaks/seized pistons	Day	●	●	●	●	●
Brake master cylinder - check for leaks	Day	●	●	●	●	●
Drive chain - lubricate	Every 200 miles (300 kms)					
Drive chain - wear check	Every 500 miles (800 kms)					
Drive chain rubbing strip - check	-		●		●	●
Drive chain rubbing strip - renew	-			●		●
Drive chain slack - check/adjust	Day	●	●	●	●	●
Fasteners - inspect visually for security	Day	●	●	●	●	●
Wheels - inspect for damage	Day	●	●	●	●	●
Tyre wear/tyre damage - check	Day	●	●	●	●	●
Tyre pressures - check/adjust	Day	●	●	●	●	●
Clutch cable - check/adjust	Day	●	●	●	●	●
Secondary air injection system - clean	-			●		●
Fuel/evaporative hoses* - renew	-					●

* Evaporative hoses fitted to California models only



WARNING: All maintenance is vitally important and must not be neglected. Incorrect maintenance or adjustment may cause one or more parts of the motorcycle to malfunction. A malfunctioning motorcycle is dangerous and may lead to an accident.

Weather, terrain and geographical location affects maintenance. The maintenance schedule should be adjusted to match the particular environment in which the vehicle is used and the demands of the individual owner.


Triumph Motorcycles cannot accept any responsibility for damage or injury resulting from incorrect maintenance or improper adjustment carried out by the owner.

Since incorrect or neglected maintenance can lead to a dangerous riding condition, always have an authorised Triumph dealer carry out the scheduled maintenance of this motorcycle.

SIDE PANEL

Side Panel Removal


- Remove both seats.
- Disconnect the battery, negative (black) lead first.



- Release the six threaded fixings and six plastic rivets from the locations shown in the diagram above.
- Paying attention to the routing of the cable leading to the seat lock mechanism, the side panel may now be carefully lifted clear as one item.

Side Panel Refitting

- Reverse the removal procedure with the exception of the following.
- Tighten the panel threaded fixings to 3 Nm.
- Tighten the rear seat lock mechanism fixings to 9Nm.
- Reconnect the battery positive (red) lead first.
- Refit the seats/cover (see general information for details).



1. Filler
2. Filler Plug/Dipstick
3. Hash Marked Area

ENGINE OIL



In order for the engine, transmission, and clutch to function correctly, maintain the engine oil at the correct level, and change the oil and oil filter in accordance with scheduled maintenance requirements.

WARNING: Motorcycle operation with insufficient, deteriorated, or contaminated engine oil will cause accelerated engine wear and may result in engine or transmission seizure. Seizure of the engine or transmission may lead to loss of control and an accident.


Oil Level Inspection

- Stop engine, then wait for at least 10 minutes to allow the oil to settle.
- Remove the filler plug/dipstick, wipe the dipstick clean and screw the plug fully home in the clutch cover.

NOTE:

- **The actual level is indicated when the motorcycle is upright, (not on the side stand) and when the filler plug/dipstick has been screwed fully home.**
- Remove the filler plug/dipstick.
- The oil level is indicated by hash marks on the filler plug/dipstick. When full, the indicated oil level must be level with the top of the hash marked area.
- If the oil level is too low, add oil a little at a time through the dipstick/filler hole until the correct level is reached.
- Once the correct level is reached, fit and fully tighten the filler plug/dipstick.

Maintenance and Adjustment



1. Oil Drain Plug
2. Oil Filter

Oil and Oil Filter Change



WARNING: Prolonged or repeated contact with engine oil can lead to skin dryness, irritation and dermatitis. In addition, used engine oil contains potentially harmful contamination which can cause cancer. Wear suitable clothing and avoid skin contact.

The engine oil and filter must be replaced in accordance with scheduled maintenance requirements.

- Warm up the engine thoroughly, and then stop the engine.
- Place an oil pan beneath the engine.
- Remove the engine drain plug.

WARNING: The oil may be hot to the touch. Avoid contact with hot oil by wearing suitable protective clothing, gloves, eye protection etc. Contact with hot oil may cause the skin to be scalded or burned.

- With the motorcycle on level ground, allow the oil to completely drain.
- Remove the lower fairings.
- Unscrew and remove the oil filter using the Triumph service tool T3880312. Discard the oil filter.
- Pre-fill the replacement oil filter with new engine oil.
- Apply a smear of clean engine oil to the sealing ring of the new oil filter. Fit the oil filter and tighten to **12 Nm**.
- After the oil has completely drained out, fit a new sealing washer to the engine drain plug. Fit and tighten the plug to **25 Nm**.
- Fill the engine with new oil of the type and grade listed in the specification section. Do not overfill.
- Start the engine and allow to idle.

CAUTION: Raging the engine before the oil reaches all parts of the engine can cause engine damage or seizure. Only raise engine speed after running the engine for a few seconds to allow the oil to circulate fully.

- Ensure that the low oil pressure warning light extinguishes shortly after starting.

CAUTION: If the engine oil pressure is too low, the low oil pressure warning light will illuminate. If this light stays on when the engine is running, stop the engine immediately and investigate the cause. Running the engine with low oil pressure will cause engine damage.

Maintenance and Adjustment

- Stop the engine and check the oil level. Adjust if necessary.
- Refit the lower fairings.

Disposal of Used Engine Oil

To protect the environment, do not pour oil on the ground, down sewers or drains, or into water courses. Dispose of used oil sensibly. If in doubt contact your local authority.

OIL SPECIFICATION & GRADE




CAUTION: Triumph high performance fuel injected engines are designed to use semi or fully synthetic motorcycle engine oil which meets specification API SH (or higher) AND JASO MA.

Do not add any chemical additives to the engine oil. The engine oil also lubricates the clutch and any additives could cause the clutch to slip.

Do not use mineral, vegetable, non-detergent oil, castor based oils or any oil not conforming to the required specification. The use of these oils may cause instant, severe engine damage.

Ensure no foreign matter enters the crankcase during an oil change or top-up.

COOLING SYSTEM



To ensure efficient engine cooling, check the coolant level each day before riding the motorcycle, and top up the coolant if the level is low.

Corrosion Inhibitors


To protect the cooling system from rust and corrosion, the use of corrosion inhibitor chemicals in the coolant is essential.

If coolant containing corrosion and rust inhibitor chemicals is not used, the cooling system will accumulate rust and scale in the water jacket and radiator. This will block the coolant passages, and considerably reduce the efficiency of the cooling system.




WARNING: Use coolant mixture containing corrosion inhibitors and anti-freeze suitable for aluminium engines and radiators. Always use the anti-freeze in accordance with the instructions of the manufacturer.

Coolant mixture which contains anti-freeze and corrosion inhibitors contains toxic chemicals which are harmful to the human body. Never swallow anti-freeze or any of the motorcycle coolant.



1. Expansion Tank
2. Tank Cap
3. 'MAX' Mark
4. 'MIN' Mark

Coolant Level Inspection



- Position the motorcycle on level ground and in an upright position.
- The coolant level in the expansion tank can be checked by removing the passenger seat/cover. The expansion tank is on the right of the seat well.
- Check the coolant level in the expansion tank. The coolant level must be between the 'MAX' (upper line) and 'MIN' (lower line) marks. If the coolant is below the minimum level, the coolant level must be adjusted.

Coolant Level Adjustment



WARNING: Do not remove the expansion tank or radiator pressure cap when the engine is hot. When the engine is hot, the coolant inside the expansion tank is hot and also under pressure. Contact with this hot, pressurised coolant will cause scalds and skin damage.

- Remove the passenger seat/cover.
- Remove bodywork as necessary to gain access to the expansion tank and filler.
- Allow the engine to cool.
- Remove the cap from the expansion tank, and add coolant mixture through the filler opening to the 'MAX' mark. Refit the cap.

NOTE

- **If the coolant level is being checked because the coolant has overheated, also check the level in the radiator and top-up if necessary.**
- **In an emergency, water alone can be added to the cooling system. However, the coolant must be returned to the correct mixture ratio as soon as possible.**
- Refit the bodywork and seat/cover.

Maintenance and Adjustment

Coolant Change

Have the coolant changed by an authorised Triumph dealer in accordance with scheduled maintenance requirements.

Radiator Hoses

Check the radiator hoses for cracks or deterioration, and hose clips for tightness in accordance with scheduled maintenance requirements. Have your authorised Triumph dealer replace any defective items.



CAUTION: A year-round type of antifreeze is installed in the cooling system when the motorcycle leaves the factory. It is coloured blue, contains a 50% solution of ethylene glycol, and has a freezing point of -35°C (-31°F).

Radiator and Cooling Fan

Check the radiator fins for obstructions by insects, leaves or mud. Clean off any obstructions with a stream of low-pressure water.




WARNING: The cooling fan operates automatically, even with the ignition switch off. Always keep hands and clothing away from the fan. Contact with the rotating fan can cause injury.



CAUTION: Using high pressure water, such as from a car wash facility, can damage the radiator fins and impair the radiator's efficiency.

Do not obstruct or deflect airflow through the radiator by installing unauthorised accessories, either in front of the radiator or behind the cooling fan. Interference with the radiator airflow can cause overheating, resulting in engine damage.



1. Throttle Grip
2. 2-3 mm
3. 'Opening' cable upper adjuster
4. 'Closing' cable

THROTTLE CONTROL



WARNING: The throttle grip controls the throttle valves in the throttle bodies. If the throttle cables are incorrectly adjusted, either too tight or too loose, the throttle may be difficult to control and performance will be adversely affected.

Check the throttle grip free-play in accordance with scheduled maintenance requirements and make adjustments as necessary.

Always be alert for changes in the 'feel' of the throttle and have the throttle system checked by an authorised Triumph dealer if any changes are detected. Changes can be due to wear in the mechanism which could lead to a sticking throttle.

An incorrectly adjusted, sticking or stuck throttle will lead to loss of motorcycle control and an accident

Inspection


- Check that the throttle opens smoothly, without undue force and that it closes without sticking. Have your authorised Triumph dealer check the throttle system if a problem is detected or any doubt exists.
- Check that there is 2-3 mm throttle grip free-play when lightly turning the throttle grip back and forth.
- If there is an incorrect amount of free-play, Triumph recommend that you have adjustments made by your authorised Triumph dealer. However, in an emergency, throttle adjustment may be made as follows:



WARNING: Use of the motorcycle with an incorrectly adjusted, incorrectly routed, sticking or damaged throttle cables will interfere with the throttle function resulting in loss of motorcycle control and an accident.

To avoid incorrect adjustment, incorrect routing, or continued use of a sticking or damaged throttle, always have your throttle checked and adjusted by your authorised Triumph dealer.

Maintenance and Adjustment



1. Locknuts
2. Adjuster nuts
3. Opening cable adjuster
4. Closing cable adjuster
5. Closing cable - measurement point

- Remove the seats.
- Disconnect the battery, negative (black) lead first.
- Remove the fuel tank.
- Release the locknut on the 'opening' cable adjuster.
- Rotate the 'opening' cable adjuster at the twist grip end such that it has an equal amount of adjustment in each direction.
- Rotate the 'opening' cable adjuster at the throttle body end of the cable to give 2-3 mm of play at the twist grip. Tighten the locknut.
- Make any minor adjustments as necessary to give 2-3 mm of play using the adjuster near the twist grip end of the cable. Tighten the locknut.
- With the throttle fully closed, ensure that there is 2-3mm of free play in the 'closing' cable. Adjust as for the 'opening' cable if necessary.

WARNING: Ensure that all the adjuster locknuts of both cables are tightened as a sticking throttle could result from a loose locknut.

An incorrectly adjusted, sticking or stuck throttle will lead to loss of motorcycle control and an accident

- Refit the fuel tank.
- Reconnect the battery, positive (red) lead first.
- Refit the seats.
- Check that the throttle opens smoothly, without undue force and that it closes without sticking.
- Ride carefully to your nearest authorised Triumph dealer and have him check the throttle system thoroughly before riding again.

Maintenance and Adjustment

CLUTCH


The motorcycle is equipped with a cable operated clutch.

If the clutch lever has excessive free-play, the clutch may not disengage fully which will cause difficulty in changing gear and may cause the engine to stall. Conversely, if the clutch lever has insufficient free-play the clutch may not engage fully, causing the clutch to slip which will reduce performance and cause premature clutch wear.

Clutch lever free-play must be checked in accordance with scheduled maintenance requirements.

Inspection

- Check that there is 2-3 mm clutch lever free-play as shown in the diagram above.
- If there is an incorrect amount of free-play, adjustments must be made.



1. Lever
2. 2-3 mm

Adjustment

- Loosen the knurled locknut at the lever end of the clutch cable and turn the adjuster sleeve until the correct amount of clutch lever free-play is achieved.
- Tighten the knurled locknut against the clutch lever assembly.
- If correct adjustment cannot be made using the lever adjuster, use the cable adjuster at the lower end of the cable.
- Remove the right hand lower fairing.
- Loosen the adjuster locknut.
- Turn the outer cable adjuster to give 2-3 mm of free-play at the clutch lever.
- Tighten the locknut.
- Refit the right hand lower fairing.

Maintenance and Adjustment

DRIVE CHAIN



For safety and to prevent excessive wear, the drive chain must be checked, adjusted, and lubricated in accordance with scheduled maintenance requirements. Checking, adjustment and lubrication must be carried out more frequently for extreme conditions such as salty or heavily gritted roads.

If the chain is badly worn or incorrectly adjusted (either too loose or too tight) the chain could jump off the sprockets or break.



WARNING: A loose or worn chain, or a chain that breaks or jumps off the sprockets could catch on the engine sprocket or lock the rear wheel

A chain that catches on the engine sprocket will injure the rider and lead to loss of motorcycle control and an accident

Similarly, locking the rear wheel will lead to loss of motorcycle control and an accident.

Chain Lubrication



Lubrication is necessary every 500 miles and also after riding in wet weather, on wet roads, or any time that the chain appears dry.

Use the special chain lubricant as recommended in the specification section.


- Apply lubricant to the sides of the rollers. This will allow the oil to penetrate to the chain rollers and bushings. Also apply oil to the chain 'O' rings. Wipe off any excess oil.
- If the chain is especially dirty, clean first using paraffin and then apply oil as mentioned above.



CAUTION: Do not use a power 'jet' wash to clean the chain as this may cause damage to the chain components.

Maintenance and Adjustment

Chain Free-movement Inspection




1. Maximum Movement Position (25-35 mm)

- Support the motorcycle on a firm, level surface with the side stand.
- Rotate the rear wheel to find the position where the chain is tightest, and measure the vertical movement of the chain midway between the sprockets.
- The vertical movement of the drive chain must be 25-35 mm.

Chain Free-movement Adjustment

- If the chain free-movement measurement is incorrect, adjustments must be made as follows:
- Loosen the wheel spindle nut.
- Release the locknuts on both the left and right chain adjuster bolts.
- Moving both adjusters by an equal amount, turn the adjuster bolts clockwise to increase chain free-movement and anti-clockwise to reduce chain free-movement.



1. Adjuster Bolt
2. Adjuster Bolt Locknut
3. Rear Wheel Spindle Nut

- When the correct amount of chain free-movement has been set, push the wheel into firm contact with the adjuster. Tighten both adjuster locknuts to 27 Nm and the rear wheel spindle nut to 110 Nm.
- Rotate the rear wheel and repeat the chain adjustment check. Re-adjust if necessary.




WARNING: Operation of the motorcycle with insecure adjuster locknuts or a loose wheel spindle may result in impaired stability and handling of the motorcycle. This impaired stability and handling may lead to loss of control or an accident.

- Check the rear brake for correct operation (i.e. that the pedal does not have excessive travel and does not feel soft or spongy).

Maintenance and Adjustment


Chain Wear Inspection



1. Measure Across 20 Links

2. Weight

- Remove the chain guard and sprocket cover.
- Stretch the chain taut by hanging a 10-20 kg (20-40 lb) weight from it.
- Measure the length of 20 links on the straight part of the chain from pin centre of the 1st pin to the centre of the 21st pin. Since the chain may wear unevenly, take measurements at several places.
- If the length exceeds the maximum service limit of 321 mm, the chain must be replaced.
- Rotate the rear wheel and inspect the drive chain for damaged rollers, and loose pins and links.
- Inspect the sprockets for unevenly or excessively worn or damaged teeth.
- If there is any irregularity, have the drive chain and/or the sprockets replaced by an authorised Triumph dealer.



! WARNING: The use of non-approved chains may result in a broken chain or may cause the chain to jump off the sprockets. Either condition could lock the rear wheel, severely damaging the motorcycle and causing loss of control and an accident.


For safety, use a genuine Triumph supplied chain as specified in the Triumph parts catalogue.

Never neglect chain maintenance and always have chains installed by an authorised Triumph dealer.

! CAUTION: If the sprockets are found to be worn, always replace the sprockets and drive chain together.

Replacing worn sprockets without also replacing the chain will lead to premature wear of the new sprockets.

- Replace the chain guard and sprocket cover.



1. Lining Thickness
2. 1.5 mm (0.06 in) Groove Thickness

BRAKES

Brake Wear Inspection

Brake pads must be inspected in accordance with scheduled requirements and replaced if worn to, or beyond the minimum service thickness.

If the lining thickness of any pad (front or rear brakes) is less than 1.5 mm (0.06 in), that is, if the pad has worn down to the bottom of the grooves, replace all the pads on the wheel.

WARNING: Brake pads must always be replaced as a wheel set. At the front, where two calipers are fitted on the same wheel, replace all the brake pads in both calipers.

Replacing individual pads will reduce braking efficiency and may cause an accident.

After replacement brake pads have been fitted, ride with extreme caution until the new pads have 'broken in'.

Brake Pad Wear Compensation

Disc and disc pad wear is automatically compensated for and has no effect on the brake lever or pedal action. There are no parts that require adjustment on the front and rear brakes.



WARNING: If the brake lever or pedal feels soft when it is applied, or if the lever/pedal travel becomes excessive, there may be air in the brake lines or the brake may be defective.

It is dangerous to operate the motorcycle under such conditions and remedial action must be taken by your authorised Triumph dealer before riding.

Riding with defective brakes may lead to loss of motorcycle control and an accident.

Brake Light Switches

The brake light is activated independently by either the front or rear brake. If the brake light does not work when the front brake lever is pulled, or the rear brake pedal depressed, ask your authorised Triumph dealer to investigate and rectify the fault.



WARNING: Riding the motorcycle with defective brake lights is illegal and dangerous.

An accident causing injury to the rider and other road users may result from use of a motorcycle with defective brake lights.

Maintenance and Adjustment

Disc Brake Fluid

Inspect the level of brake fluid in both reservoirs and change the brake fluid in accordance with scheduled maintenance requirements. Use only DOT 4 fluid as recommended in the specification section. The brake fluid must also be changed if it becomes, or is suspected of having become contaminated with moisture or any other contaminants.



WARNING: If the brake fluid in either reservoir has become, or is suspected of having become contaminated, consult your authorised Triumph dealer for advice, before riding. Contaminated brake fluid may cause the brakes to become defective. Riding with defective brakes may lead to loss of motorcycle control and an accident.



WARNING: Brake fluid is hygroscopic which means it will absorb moisture from the air.

Any absorbed moisture will greatly reduce the boiling point of the brake fluid causing a reduction in braking efficiency.

Because of this, always replace brake fluid in accordance with scheduled maintenance requirements.

Always use new brake fluid from a sealed container and never use fluid from an unsealed container or from one which has been previously opened.


Do not mix different brands or grades of brake fluid.

Check for fluid leakage around brake fittings, seals and joints and also check the brake hoses for splits, deterioration and damage.

Always rectify any faults before riding.

Failure to observe and act upon any of these items may cause a dangerous riding condition leading to loss of control and an accident.


Maintenance and Adjustment



1. Upper Level, Front Brake
2. Lower Level, Front Brake
3. Safety Clip

Brake Fluid Level Inspection and Adjustment

- The brake fluid level in the reservoirs must be kept between the upper and lower level lines (reservoir held horizontal).
- At the rear, remove the seat and rear bodywork.
- Remove the safety clip (front only).
- Fill the reservoir to the upper level line using new DOT 4 fluid from a sealed container.
- Refit the reservoir cap ensuring that the diaphragm seal is correctly fitted.
- Refit the safety clip.
- At the rear, refit the seat and rear bodywork.




1. Upper Level, Rear Brake
2. Lower Level, Rear Brake



WARNING: If there has been an appreciable drop in the level of fluid in either fluid reservoir, consult your authorised Triumph dealer before riding. Riding with depleted brake fluid levels or with a brake fluid leak is dangerous and will cause reduced brake performance potentially leading to loss of motorcycle control and an accident.

WINDSCREEN CLEANING



Always clean the windscreen with clean water and a soft cloth. Dry after cleaning with a soft, lint free cloth. Minor scratches can be removed using a commercial polishing compound suitable for plastic.

The windscreen must be replaced if scratches cannot be completely removed.



WARNING: Never attempt to clean the windscreen while the motorcycle is in motion as releasing the handlebars may cause loss of vehicle control and an accident.

Operation of the motorcycle with a damaged or scratched windscreen will reduce the rider's forward vision. Any such reduction in forward vision is dangerous and may lead to an accident causing injury or death.



CAUTION: Corrosive chemicals such as battery electrolyte will damage the windscreen. Never allow corrosive chemicals to contact the windscreen.

STEERING/WHEEL BEARINGS

Steering Inspection

Lubricate and inspect the condition of the headstock (steering) bearings in accordance with scheduled maintenance requirements.

NOTE


- Always inspect the wheel bearings at the same time as the steering bearings.



WARNING: To prevent risk of injury from the motorcycle falling during the inspection, ensure that the motorcycle is stabilized and secured on the support block.

Do not exert extreme force against each wheel or rock each wheel vigorously as this may cause the motorcycle to become unstable or cause injury by falling from its support.

Ensure that the position of the support block will not cause damage to the oil lines beneath the sump.



Inspecting the Steering for Free-Play Inspection

- Position the motorcycle on level ground, in an upright position.
- Raise the front wheel off the ground and support the motorcycle.
- Hold the lower end of the front forks and try to move them forward and backward.
- If any free-play can be detected, ask your authorised Triumph dealer to inspect and rectify any faults before riding.

! WARNING: Riding the motorcycle with incorrectly adjusted or defective steering may cause loss of motorcycle control and an accident.

- Remove the support and place the motorcycle on the side stand.

Wheel Bearings Inspection

If the wheel bearings in the front or rear wheel allow play in the wheel hub, are noisy, or if the wheel does not turn smoothly, have your authorised Triumph dealer inspect the wheel bearings.

The wheel bearings must be inspected at the intervals specified in the scheduled maintenance chart.

- Position the motorcycle on level ground, in an upright position.
- Raise the front wheel off the ground and support the motorcycle.
- Gently rock the top of the front wheel from side to side.
- If any free-play can be detected, ask your authorised Triumph dealer to inspect and rectify any faults before riding.
- Reposition the lifting device and repeat for the rear wheel.

! WARNING: Operation with worn or damaged wheel bearings may cause impaired handling and instability leading to an accident. If in doubt, have the motorcycle inspected by an authorised Triumph dealer before riding.

- Remove the support and place the motorcycle on the side stand.

Maintenance and Adjustment

FRONT SUSPENSION

Front Fork Inspection


- Examine each fork stanchion for any sign of damage, scratching of the slider surface, or for oil leaks.
- If any damage or leakage is found consult an authorised Triumph dealer.

To check that the forks operate smoothly:

- Position the motorcycle on level ground.
- While holding the handlebars and applying the front brake, pump the forks up and down several times.


NOTE:


- The suspension movement will be affected by different adjustment settings.
- If roughness or excessive stiffness is detected, consult your authorised Triumph dealer.


 **WARNING:** Riding the motorcycle with defective or damaged suspension can damage the motorcycle, cause loss of control, or an accident.

SUSPENSION SETTING

The standard suspension settings provide a comfortable ride and good handling characteristics for general, solo riding. The chart on the following page shows suggested settings for front and rear suspension.

 **WARNING:** Never attempt to dismantle any part of the suspension units, as all units contain pressurised oil. Skin and eye damage can result from contact with the pressurised oil.

 **WARNING:** Ensure that the correct balance between front and rear suspension is maintained. Suspension imbalance could significantly change handling characteristics leading to loss of control and an accident. Refer to the chart overleaf for further information or consult your Triumph dealer.

 **WARNING:** Ensure that the adjusters are set to the same setting on both forks. Settings which vary from left to right hand forks may affect handling resulting in loss of control, and an accident.

NOTE:

- The setting figures over-page are all measured as clicks out from the fully screwed in position unless stated otherwise.

Maintenance and Adjustment

LOADING		FRONT			REAR		
		SPRING PRE-LOAD+	REBOUND DAMPING*	COMP'N DAMPING*	REBOUND DAMPING*	COMP'N DAMPING*	SPRING PRE-LOAD
SOLO RIDING	STANDARD	6	6	6	6	6	N/A
	SOFTER	8	8	8	8	8	N/A
	FIRMER	3	4	4	4	4	N/A
RIDER AND PASSENGER		3	4	4	4	4	N/A
* Number of adjuster clicks out from the fully screwed in position. + Number of visible graduation lines.							

NOTE:

This chart is only a guide. Setting requirements may vary for rider weight and personal preferences. See the following pages for details of how to adjust your suspension.

Adjuster Location

Front

The spring pre-load and rebound damping adjusters are located at the top of each fork.


The compression damping adjusters are located at the bottom of each fork.

Rear

The compression damping adjuster is located on the damping fluid reservoir.

The rebound damping adjuster is located at the base of the suspension unit on the left hand side of the motorcycle.


The spring pre-load adjuster cannot be reset with the suspension unit in the frame. Please refer to your authorised Triumph dealer for adjustment of this item.



WARNING: Owners should not attempt to adjust the rear suspension spring pre-load setting.

Only an authorised Triumph dealer has the necessary tools, equipment and specialist knowledge to make adjustments to the rear suspension pre-load settings. In addition, due to the forces of the rear spring under compression, specialist safety equipment is also needed if the adjustment is to be made without risk of injury.

Making adjustments without this specialist knowledge, or without access to the necessary specialist tools and safety equipment could cause personal injury and a dangerous riding condition leading to loss of motorcycle control and an accident.



1. Spring Pre-load Adjuster
2. Rebound Damping Force Adjuster

Front spring Pre-load Adjustment


To change the spring pre-load, rotate the adjuster clockwise (screw-in) to increase pre-load, or anti-clockwise (screw-out) to decrease pre-load. Always set the pre-load adjusters such that there are an equal number of graduation lines visible on both forks.

NOTE:

- The motorcycle is delivered from the factory with the spring pre-load adjuster set on position 6.

Front Compression Damping Adjustment

To change the compression damping force rotate the slotted adjuster clockwise (screw-in) to increase, or anti-clockwise (screw-out) to decrease. Maximum damping force is obtained when the adjuster is rotated fully clockwise (screwed fully in). Minimum damping force is obtained when the adjuster is rotated fully anti-clockwise (screwed fully out). Always count the clicks out from the screwed fully in position and set both forks to the same setting.



3. Compression Damping Force Adjuster

NOTE:

- The motorcycle is delivered from the factory with the compression damping adjuster set at position 6.

Front Rebound Damping Adjustment


To change the rebound damping force, rotate the slotted adjuster clockwise (screw-in) to increase, or anti-clockwise (screw-out) to decrease. Always count the clicks out from the screwed fully in position and set both forks to the same position.

Maximum damping force is obtained when the adjuster is rotated fully clockwise (screwed fully in).

Minimum damping force is obtained when the adjuster is rotated fully anti-clockwise (screwed fully out).

NOTE:

- The motorcycle is delivered from the factory with the rebound damping force adjuster set at position 6.



1. Rebound Damping Adjuster

REAR SUSPENSION ADJUSTMENT

The rear suspension unit is rider-adjustable for both compression and rebound damping.


Rear Rebound Damping Adjustment

The rebound damping adjuster is situated at the lower left hand end of the rear suspension unit.

To adjust the rebound damping setting, rotate the adjuster clockwise to increase rebound damping and anti-clockwise to decrease.

NOTE

- The settings are all measured as the number of adjuster clicks out from the fully screwed in position.
- The motorcycle is delivered from the factory with the rebound damping adjuster set to position 6.



1. Compression Damping Adjuster

Rear Compression Damping Adjustment


The compression damping adjuster is situated on the rear suspension unit reservoir.

To adjust the compression damping setting, rotate the slotted adjuster clockwise (screw-in) to increase, or anti-clockwise (screw-out) to decrease.


NOTE:

- The motorcycle is delivered from the factory with the compression damping adjuster set to position 6.

Maintenance and Adjustment



Typical Tyre Marking



Wheel Marking

TYRES



This motorcycle is equipped with tubeless tyres, valves and wheel rims. Use only tyres marked 'TUBELESS' and tubeless valves on rims marked 'SUITABLE FOR TUBELESS TYRES'.

Tyre Inflation Pressures

Correct inflation pressure will provide maximum stability, rider comfort and tyre life. Always check tyre pressures before riding when the tyres are cold. Check tyre pressures daily and adjust if necessary. See the specification section for details of the correct inflation pressures. Alternatively, ask your authorised Triumph dealer to inspect your wheels and tyres.

WARNING: Incorrect tyre inflation will cause abnormal tread wear and instability problems which may lead to loss of control and an accident.

Under-inflation may result in the tyre slipping on, or coming off the rim. Over-inflation will cause instability and accelerated tread wear.

Both conditions are dangerous as they may cause loss of control leading to an accident.

Maintenance and Adjustment

Tyre Wear



As the tyre tread wears down, the tyre becomes more susceptible to punctures and failure. It is estimated that 90% of all tyre problems occur during the last 10% of tread life (90% worn). It is, therefore, false economy and unsafe to use tyres until they are worn to their minimum.

In accordance with the periodic maintenance chart, measure the depth of the tread with a depth gauge, and replace any tyre that has worn to the minimum recommended tread depth specified in the table below.

Minimum Recommended Tread Depth

Under 130 km/h (80 mph)	2 mm (0.08 in)
Over 130 km/h (80 mph)	Rear 3 mm (0.12 in) Front 2 mm (0.08 in)



WARNING: This motorcycle must not be operated above the legal road speed limit except in authorised closed course conditions.



WARNING: Only operate this Triumph motorcycle at high speed in closed-course on-road competition or on closed course race tracks. High speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high speed riding and are familiar with the motorcycle's characteristics in all conditions. High speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.



WARNING: Operation with excessively worn tyres is hazardous and will adversely affect traction, stability and handling which may lead to loss of control and an accident.

When tubeless tyres become punctured, leakage is often very slow. Always inspect tyres very closely for punctures. Check the tyres for cuts, imbedded nails or other sharp objects. Operation with punctured or damaged tyres will adversely affect stability and handling which may lead to loss of control or an accident.

Check the rims for dents or deformation. Operation with damaged or defective wheels or tyres is dangerous and loss of control or an accident could result.

Always consult your authorised Triumph dealer for tyre replacement, or for a safety inspection of the tyres.

Maintenance and Adjustment

Tyre Replacement

All Triumph motorcycles are carefully and extensively tested in a range of riding conditions to ensure that the most effective tyre combinations are approved for use on each model. It is essential that approved tyres, fitted in approved combinations, are used when purchasing replacement tyres. The use of non approved tyres, or approved tyres in non approved combinations, may lead to motorcycle instability and an accident. See the specification section for details of approved tyre combinations. Always have tyres fitted and balanced by your authorised Triumph dealer who has the necessary training and skills to ensure safe, effective fitment.



WARNING: If a tyre sustains a puncture, the tyre must be replaced. Failure to replace a punctured tyre, or operation with a repaired tyre can lead to instability, loss of control or an accident.



WARNING: Do not install tube-type tyres on tubeless rims. The bead will not seat and the tyres could slip on the rims, causing rapid tyre deflation that may result in a loss of vehicle control and an accident. Never install an inner tube inside a tubeless tyre. This will cause friction inside the tyre and the resulting head build-up may cause the tube to burst resulting in rapid tyre deflation, loss of vehicle control and an accident.



WARNING: If tyre damage is suspected, such as after striking the kerb, ask your authorised Triumph dealer to inspect the tyre both internally and externally. Remember, tyre damage may not always be visible from the outside. Operation of the motorcycle with damaged tyres could lead to loss of control and an accident.



WARNING: When replacement tyres are required, consult your authorised Triumph dealer who will arrange for the tyres to be selected, in a correct combination, from the approved list and fitted according to the tyre manufacturer's instructions.

When tyres are replaced, allow time for the tyres to seat to the rim (approximately 24 hours). During this seating period, ride cautiously as an incorrectly seated tyre could cause loss of control or an accident.

Initially, the new tyres will not produce the same handling characteristics as the worn tyres and the rider must allow adequate riding distance (approximately 100 miles) to become accustomed to the new handling characteristics.

Maintenance and Adjustment



WARNING: (continued from previous page): 24 hours after fitting, the tyre pressures must be checked and adjusted, and the tyres examined for correct seating. Rectification must be carried out as necessary.

The same checks and adjustments must also be carried out when 100 miles have been travelled after fitting.

Use of a motorcycle with incorrectly seated tyres, incorrectly adjusted tyre pressures, or when not accustomed to its handling characteristics may lead to loss of control and an accident.



WARNING: Accurate wheel balance is necessary for safe, stable handling of the motorcycle. Do not remove or change any wheel balance weights. Incorrect wheel balance may cause instability leading to loss of control and an accident.

When wheel balancing is required, such as after tyre replacement, see your authorised Triumph dealer.

Only use self-adhesive weights. Clip on weights may damage the wheel and tyre resulting in tyre deflation, loss of control and an accident.



WARNING: Tyres that have been used on a rolling road dynamometer may become damaged. In some cases, the damage may not be visible on the external surface of the tyre.

Tyres must be replaced after such use as continued use of a damaged tyre may lead to instability, loss of control and an accident.

Maintenance and Adjustment

BATTERY



WARNING: Under some circumstances, the battery can give off explosive gases; keep sparks, flames and cigarettes away. Provide adequate ventilation when charging or using the battery in an enclosed space.

The battery contains sulphuric acid (electrolyte). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield.


- If electrolyte gets on your skin, flush with water immediately.
- If electrolyte gets in your eyes, flush with water for at least 15 minutes and **SEEK MEDICAL ATTENTION IMMEDIATELY.**
- If electrolyte is swallowed, drink large quantities of water and **SEEK MEDICAL ATTENTION IMMEDIATELY.**

KEEP ELECTROLYTE OUT OF THE REACH OF CHILDREN.

WARNING: The battery contains harmful materials. Always keep children away from the battery whether or not it is fitted in the motorcycle.

Do not jump start the battery, touch the battery cables together or reverse the polarity of the cables as any of these actions may cause a spark which would ignite battery gases causing a risk of personal injury.


Battery Disposal



Should the battery ever require replacement, the original battery must be handed to a recycling agent who will ensure that the dangerous substances from which the battery is manufactured do not pollute the environment.

Maintenance and Adjustment

Battery Removal



1. Battery
2. Negative (-) Terminal
3. Positive (+) Terminal

- Remove the seat
- Remove the battery strap.
- Disconnect the battery leads, negative (black) lead first.
- Take the battery out of the case.

! **WARNING:** Ensure that the battery terminals do not touch the motorcycle frame as this may cause a short circuit or spark which would ignite battery gases causing a risk of personal injury.

- Clean the battery using a clean, dry, cloth. Be sure that the cable connections are clean.

Battery Maintenance

! **WARNING:** The battery electrolyte is corrosive and poisonous and will cause damage to unprotected skin. Never swallow battery electrolyte or allow it to come into contact with the skin. To prevent injury, always wear eye and skin protection when handling the battery.

The battery is a sealed type and will not require any maintenance other than routine recharging, such as during storage.

It is not possible to adjust the electrolyte level in the battery.

Maintenance and Adjustment


Battery Installation



WARNING: Ensure that the battery terminals do not touch the motorcycle frame as this may cause a short circuit or spark which would ignite battery gases causing a risk of personal injury.

- Place the battery in the battery case.
- Reconnect the battery, positive (red) lead first.
- Apply a light coat of grease to the terminals to prevent corrosion.
- Cover the positive terminal with the protective cap.
- Refit the battery strap.
- Refit the seat.

FUSE BOXES



1. Panel Fixings

2. Front Fuse Box


This motorcycle is fitted with two fuse boxes.

The front fuse box is located under the left hand cockpit infill panel. The rear fuse box is located under the passenger seat.

To allow access to the rear fuse box, the rider's seat must be removed.

To allow access to the front fuse box, the cockpit infill panel must be removed as follows:

- Release cockpit infill fixings shown in diagram above.
- Ensuring that the front wheel is pointing straight ahead (which allows space for removal), detach the panel.
- Refitting is the reverse of removal.
- Ensure that the cockpit infill panel is fitted correctly and does not impede the movement of any cables or harnesses. Tighten the in-fill panel screws to 3 Nm.



1. Rear Fuse Box



WARNING: Always replace blown fuses with new ones of the correct rating (as specified on the fuse box cover) and never use a fuse of higher rating.

Use of an incorrectly rated fuse could lead to an electrical problem, resulting in motorcycle damage, loss of motorcycle control and an accident.

Fuse Identification

A blown fuse is indicated when all of the systems protected by that fuse become inoperative. When checking for a blown fuse, use the table below to establish which fuse has blown.

Front fuse box

Fuse No	Circuits Protected	Fuse Rating (Amp.)
1	Ignition/starter circuit	10
2	Instrument illumination	5
3	Main lighting system	20
4	Position lights	5

Rear fuse box

Fuse No	Circuits Protected	Fuse Rating (Amp.)
1	Dip & main beam	15
2	Ignition switch main feed	30
3	Diagnostics/alarm/instrument memory	10
4	Indicators/brake lights/horn	15
5	Engine management system	20
6	Cooling fan	15

NOTE:

- The fuse identification numbers listed above correspond with those printed on the fuse box cover.

Maintenance and Adjustment

HEADLIGHTS



WARNING: Adjust road speed to suit the visibility and weather conditions in which the motorcycle is being operated.

Ensure that the beam is adjusted to illuminate the road surface sufficiently far ahead without dazzling oncoming traffic. An incorrectly adjusted headlight may impair visibility causing an accident.




WARNING: Never attempt to adjust the headlamp beam when the motorcycle is in motion.

Any attempt to adjust the headlamp beam when the motorcycle is in motion may result in loss of control and an accident.

NOTE:

- The left and right hand headlights are adjusted independently. Unless stated, the following instructions apply to either headlight but the adjustments made will only affect the particularly light being adjusted.
- On the **left hand** headlight, turn the horizontal adjustment screw anti-clockwise to move the headlight beam to the right, and clockwise to move the beam to the left.
- On the **right hand** headlight, turn the horizontal adjustment screw anti-clockwise to move the headlight beam to the left, and clockwise to move the beam to the right.
- Switch the headlights off when both beam settings are satisfactory.



1. Vertical Adjustment Screw
2. Horizontal Adjustment Screw

Headlight Adjustment


- Switch the headlight dipped beam on.
- Turn the vertical adjustment screw clockwise to lower the beam or anti-clockwise to raise the beam.

Maintenance and Adjustment

Headlight/Position Light Bulb Replacement

It is not necessary to remove the headlight to gain access to either bulb.

- Remove the front seat.
- Disconnect the battery, negative (black) lead first.
- Remove the cockpit infill panels to allow access to the position lamps. See 'Fuses'.
- To remove the position light bulb, disconnect the multi-plug then pull the bulb holder (NOT the wires) until it is released from the housing.
- To remove the bulb from the holder, gently pull on the bulb until it is released.
- To remove the headlight bulb, disconnect the multi-pin electrical connector from the headlight bulb and remove the rubber cover.
- Detach the wire bulb retainer from the clip. It is not necessary to undo the screw.
- Remove the bulb from the headlight.
- Installation for both bulbs is the reverse of the removal procedure.



1. Headlight Bulb Retainer
2. Position Light



WARNING: The bulb becomes hot during use. Always allow sufficient time for the bulb to cool before handling.

Avoid touching the glass part of the bulb. If the glass is touched or gets dirty, clean with alcohol before re-use.




CAUTION: When reconnecting the battery, connect the positive (red) lead first.



WARNING: Do not reconnect the battery until the assembly process has been completed. Premature battery reconnection could result in ignition of the battery gases causing risk of injury.

Maintenance and Adjustment




1. Rear Light Bulb Retainer
2. Seat catch fixings.

REAR LIGHT

Bulb Replacement

- Remove the rear seat and the rear seat lock fixings to gain access to the rear light bulb holders.
- Rotate each bulb holder anti-clockwise to release.
- Replace the bulbs. Insert the bulb holders to the rear light unit and turn each clockwise to secure in the light unit.
- Replace the rear seat lock and tighten fixings to 9Nm.
- Check rear seat lock and rear light for correct operation.
- Refit the seat.



1. Indicator Lens
2. Securing Screw

INDICATOR LIGHTS

Bulb Replacement

- The lens on each indicator light is held in place by a securing screw located in the body of the light.
- Release the screw and remove the amber lens to gain access to the bulb for replacement.

Maintenance and Adjustment

CLEANING

Frequent, regular cleaning is an essential part of the maintenance of your motorcycle. If regularly cleaned, the appearance will be preserved for many years. Cleaning with warm water containing an automotive cleaner is essential at all times but particularly so after exposure to sea breezes, sea water, dusty or muddy roads and in winter when roads are treated for ice and snow.

Although, under the terms of your motorcycle warranty, cover is provided against the corrosion of certain items, the owner is expected to observe this reasonable advice which will safeguard against corrosion and enhance the appearance of the motorcycle. Do not use household detergent as the use of such products will lead to premature corrosion.

Preparation for Washing

Before washing, precautions must be taken to keep water off the following places.

- Rear opening of the muffler: Cover with a plastic bag secured with rubber bands.
- Clutch and brake levers, switch housings on the handlebar: Cover with plastic bags.
- Ignition switch: Cover the keyhole with tape.

Where to be Careful

Avoid spraying water with any great force near the following places:

- Instruments.
- Brake cylinders and brake calipers.
- Under the fuel tank.
- Drive chain and headstock bearings.

NOTE:

- **Coin operated, high pressure spray washers are not recommended. The water may be forced into bearings and other components often causing deterioration from rust and corrosion. Some of the soaps which are highly alkaline leave a residue or cause spotting.**

After Washing

- Remove the plastic bags and tape, and clear the air intakes.
- Lubricate the pivots, bolts and nuts.
- Test the brakes before motorcycle operation.
- Start the engine and run it for 5 minutes. **Ensure adequate ventilation for the exhaust fumes.**
- Use a dry cloth to absorb water residue. Do not allow water to stand on the machine as this will lead to corrosion.

Maintenance and Adjustment



WARNING: Never wax or lubricate the brake discs. Loss of braking power and an accident could result. Clean the disc with a proprietary brand of oil free brake disc cleaner.

Unpainted Aluminium Items

- Items such as brake and clutch levers must be correctly cleaned to preserve their appearance.
- Use a proprietary brand of aluminium cleaner which does not contain abrasive or caustic elements.
- Clean aluminium items regularly, in particular after use in inclement weather, where the components must be hand washed and dried each time the machine is used.
- Warranty claims due to inadequate maintenance will not be allowed.

Cleaning of the Exhaust System:

All parts of the exhaust system of your motorcycle must be cleaned regularly to avoid a deterioration of its appearance. These instructions can be applied to black chrome, brushed stainless steel and carbon fibre components alike.

NOTE:

- **The exhaust system must be cool before washing to prevent water spotting.**

Washing

- Prepare a mixture of water and mild soap. Do not use a high alkaline content soap as commonly found at commercial car washes because it leaves a residue.

- Wash the exhaust system with a soft cloth. Do not use an abrasive scouring pad or steel wool. They will damage the finish.
- Rinse the exhaust system thoroughly.
- Ensure no soap or water enters the mufflers.

Drying

- Dry the exhaust system completely with a soft cloth. Do not run the engine to dry the system or spotting will occur.

Protecting

- When the exhaust system is dry, rub 'Motorex 645 Clean And Protect' into the surface.




CAUTION: The use of silicone products such as WD40 will cause discolouration of the chrome and must not be used. Similarly, the use of abrasive cleaners such as Solvol Autosol will damage the system and must not be used.

- It is recommended that regular protection be applied to the system as this will both protect and enhance the system's appearance.

Storage

Preparation for Storage:

- Clean the entire vehicle thoroughly.
- Empty the fuel from the fuel tank into a secure container.

 WARNING: Petrol is extremely flammable and can be explosive under certain conditions. Turn the ignition switch OFF. Do not smoke. Make sure the area is well ventilated and free from any source of flame or sparks; this includes any appliance with a pilot light.

- Remove the spark plugs and put several drops (5 ml) of engine oil into each cylinder. Push the starter button for a few seconds to coat the cylinder walls with oil, and install the spark plugs.
- Reduce tyre pressure by about 20%.
- Set the motorcycle on a box or stand so that both wheels are raised off the ground. (If this cannot be done, put boards under the front and rear wheels to keep dampness away from the tyre rubber).
- Spray oil on all unpainted metal surfaces to prevent rusting. Prevent oil from getting on rubber parts, brake discs or in the brake calipers.
- Lubricate the drive chain and all the control cables.
- Remove the battery, and store it where it will not be exposed to direct sunlight, moisture, or freezing temperatures. During storage it should be given a slow charge (one ampere or less) about once a month. Keep the battery well charged during

cold weather so that the electrolyte does not freeze and crack the battery. The more discharged the battery becomes, the more easily it freezes.

- Tie plastic bags over the exhaust pipe to prevent moisture from entering.
- Put a cover over the motorcycle to keep dust and dirt from collecting on it.

Preparation after Storage:

- Charge the battery if necessary, and install it in the motorcycle.
- Fill the fuel tank with fuel.
- Change the engine oil and filter.
- Check all the points listed in the daily safety checks section.
- Before starting the engine, remove spark plugs.
- Put side stand down.
- Crank the engine on the starter motor several times until the oil pressure light goes out.
- Replace spark plugs and start engine.
- Check brakes and operation.

Specifications

Contents

Engine	84
Performance	84
Dimensions	84
Lubrication	84
Cooling	85
Fuel System	85
Fuel	85
Ignition	85
Transmission	85
Tyres	86
Electrical equipment	87
Frame	87
Tightening Torques	87
Fluid and Lubricants	87

Specifications

DAYTONA 650

ENGINE

Type	in-line 4 cyl.
Displacement	646cc
Bore x Stroke	68 x 44.5mm
Compression Ratio	12.85:1
Cylinder Numbering	Left to Right
Sequence	1-2-3-4
Firing Order	1-2-4-3

PERFORMANCE

Maximum Power (DIN)	114 PS @ 12,500 rpm
Maximum Torque	68 Nm @ 11,500 rpm

DIMENSIONS

Overall Length	2112 mm
Overall Width	712 mm
Overall Height	1131 mm
Wheelbase	1390 mm
Seat Height	815 mm
Dry Weight	165 kg
Maximum Payload	195 kg (rider, passenger & accessories)

LUBRICATION

Lubrication System	Forced (wetsump) Lubrication
Engine Oil Capacity (dry fill)	4.50 litres
(oil/filter change)	4.30 litres
(oil change only)	4.10 litres

Specifications

DAYTONA 650

COOLING

Coolant Type	Mobil Antifreeze
Mixture Ratio	50/50
Coolant Capacity	2.5 litre
Thermostat Opens (nominal)	84°C

FUEL SYSTEM

Type	Electronic multi-point fuel injection with twin butterfly throttle bodies
Fuel Pump	Submerged Electric
Fuel Pressure	3 Bar

FUEL

Type	Unleaded (95 RON)
Tank Capacity	18 Litres

IGNITION

Ignition System	Digital Inductive
Spark Plug	NGK CR9EK
Gap	0.60-0.75mm (0.70 mm nominal)

TRANSMISSION

Transmission Type	6 Speed, Constant Mesh
Clutch Type	Wet, Multi-Plate

Specifications

DAYTONA 650

TRANSMISSION (continued)

Final Drive	Chain, DID 525VM2 106 Link Endless
Primary Drive Ratio	1.864 (82/44)
Final Drive Ratio	3.000 (15/45)
Gear Ratio: 1st	2.923 (38/13)
2nd	2.063 (33/16)
3rd	1.632 (31/19)
4th	1.381 (29/21)
5th	1.217 (28/23)
6th	1.083 (26/24)

TYRES

Tyre Pressures (Cold)

Front	34 lb/in ² (2.4 kg/cm ²)
Rear	38 lb/in ² (2.7 kg/cm ²)

Approved tyres

Option 1 .. Front	Pirelli Diablo T 58W 120/70 ZR17
Rear	Pirelli Diablo T 73W 180/55 ZR17
Option 2 .. Front	Michelin Pilot Sport 120/70 R17
Rear	Michelin Pilot Sport 180/55 R17
Option 3 .. Front	Bridgestone BT012 (f) 120/70 R17
Rear	Bridgestone BT012 180/55 R17
Option 4 .. Front	Metzeler Sportec M1 120/70 R17
Rear	Metzeler Sportec M1 180/55 R17



WARNING: Use recommended tyre options ONLY in the combinations given. Do not mix tyres from different manufacturers or mix different specification tyres from the same manufacturers as this may result in loss of motorcycle control and an accident

Specifications

DAYTONA 650

ELECTRICAL EQUIPMENT

Battery	12V 10AH
Alternator	12V 33.5A
Headlight	2 x 12V 60/55W Halogen H4
Tail/Brake Light	2x12V 5/21W
Directional Indicator Lights	12V 10W

FRAME

Castor	24.6°
Trail	89.1 mm

Tightening Torques

Oil Filter	12 Nm
Sump Drain Plug	25 Nm
Spark Plug	18 Nm
Rear Wheel Nut	110 Nm

FLUIDS AND LUBRICANTS

Engine Oil:

Semi or fully synthetic 10W/40 or 15W/50 motorcycle engine oil which meets specification API SH (or higher) and JASO MA, such as	Mobil 1 Racing 4T (fully synthetic) or Mobil Extra 4T (semi-synthetic)
Brake and Clutch Fluid	Mobil Universal Brake & Clutch Fluid DOT4
Coolant	Mobil Antifreeze
Bearings and Pivots	Mobil Grease HP 222
Drive Chain	Mobil Chain Spray or Mobilube HD 80

Alphabetical Index

- BATTERY, Page 73
 - Battery Disposal., Page 73
 - Battery Installation., Page 75
 - Battery Maintenance, Page 74
 - Battery Removal., Page 74
- BRAKES, Page 60
 - Brake Fluid Level Inspection And Adjustment., Page 62
 - Brake Light Switches., Page 60
 - Brake Pad Wear Compensation., Page 60
 - Brake wear Inspection., Page 60
 - Disc Brake Fluid., Page 61
- BRAKING, Page 36
 - Front Brake Lever., Page 36
 - Rear Brake Padal., Page 36
- CHANGING GEARS, Page 35
 - Gear Change Pedal., Page 35
- CLEANING, Page 80
 - Cleaning Of The Exhaust System., Page 81
- Cleaning, Untreated Items, ii
- CLUTCH, Page 56
 - Adjustment., Page 56
 - Inspection., Page 56
- CONSIDERATIONS FOR HIGH SPEED OPERATION, Page 39
 - Brakes., Page 39
 - Coolant., Page 40
 - Electrical Equipment., Page 40
 - Engine Oil., Page 40
 - Fuel., Page 40
 - Luggage., Page 39
 - Miscellaneous, Page 40
 - Steering., Page 39
 - Tyres., Page 39
- COOLING, Page 85
- COOLING SYSTEM, Page 51
 - Coolant Change., Page 53
 - Coolant Level Adjustment., Page 52
 - Coolant level inspection., Page 52
 - Corrosion Inhibitors., Page 51
 - Radiator And Cooling fan., Page 53
 - Radiator Hoses., Page 53
- DAILY SAFETY CHECKS, Page 31
 - Clutch., Page 31
 - Coolant., Page 32
 - Drive Chain., Page 31
 - Electrical Equipment, Page 32
 - Engine Oil., Page 31
 - Engine Stop, Page 19, Page 30, Page 31, Page 32
 - Front Forks., Page 31
 - Fuel., Page 31
 - Nuts, Bolts, Fasteners., Page 31
 - Stands., Page 32
 - Steering., Page 31
 - Throttle., Page 31
 - Tyres/Wheels., Page 31
- DRIVE CHAIN, Page 57
 - Chain Free Movement Adjustment, Page 58
 - Chain Free Movement Inspection., Page 58
 - Chain Lubrication., Page 57
 - Chain wear Inspection., Page 59

Alphabetical Index

- ELECTRICAL EQUIPMENT, Page 87
- ENGINE, Page 84
 - Engine Serial Number., Page 15
 - Vehicle Identification Number (V.I.N.), Page 15
- ENGINE OIL, Page 49
 - Diposal Of Used Engine Oil., Page 51
 - Oil And Oil Filter Change., Page 50
 - Oil Level Inspection., Page 49
 - Specification & Grade, Page 51
- FLUIDS AND LUBRICANTS, Page 87
- FRAME, Page 87
- FUEL REQUIREMENT, Page 26
 - Filling the Fuel Tank., Page 27
 - Fuel tank Cap., Page 27
 - Refuelling, Page 26
- FUEL SYSTEM, Page 85
- FUSES, Page 75
 - Front Fuse Box, Page 75
 - Fuse identification, Page 76
 - Rear Fuse Box., Page 76
- HANDBOOK LOCATION, Page 28
- HEADLIGHTS, Page 77
 - Headlight Adjustment, Page 77
 - Headlight/Position Light Bulb replacement., Page 78
- IGNITION, Page 85
- INDICATOR LIGHTS, Page 79
 - Bulb Replacement., Page 79
- INSTRUMENT DISPLAY
 - Clock Adjustment., Page 19
 - Coolant Temperature Gauge., Page 20
 - Low Oil Pressure Warning., Page 20
 - Odometer/Trip Meter/Clock, Page 19
- INSTRUMENTS
 - Instrument Panel layout., Page 18
 - Tachometer., Page 18
- LEFT HANDLEBAR SWICHES, Page 25
 - Direction Indicator switch, Page 25
 - Headlight Dip Switch., Page 25
 - Horn Button., Page 25
 - Pass Button., Page 25
- LOCK BARREL
 - Ignition Key., Page 22
 - Ignition Switch Positions., Page 23
 - Ignition Switch/Steering Lock., Page 22
- LUBRICATION, Page 84
- PARKING, Page 38
- PARTS IDENTIFICATION, Page 12
- PREPARATION AFTER STORAGE, Page 82
- PREPARATIONS FOR STORAGE, Page 82
- REAR LIGHTS, Page 79
 - Bulb Replacement., Page 79
- RIGHT HANDLEBAR CONTROLS, Page 24
 - Brake Lever adjuster, Page 23
 - Engine Stop Switch., Page 24
 - Starter Button., Page 24

Alphabetical Index

- RUNNING IN, Page 30
0 - 500 miles (800 kms), Page 30
500 - 1000 miles (800 - 1500 kms),
Page 30
After running in, Page 30
- SAFETY FIRST
Crash Helmet and clothing., Page 5
Fuel and exhaust fumes., Page 4
Handlebars and Footrests, Page 5
Maintenance and Equipment, Page 8
Parking., Page 7
Parts and Accessories., Page 7
Riding., Page 6
The Motorcycle., Page 4
- SCHEDULED MAINTENANCE, Page 46
- SEAT FIXINGS
Front Seat Fixings., Page 29
Rear Seat Fixings., Page 29
Seat Lock., Page 29
- SIDE PANEL, Page 48
Side Panel Refitting., Page 48
Side Panel Removal., Page 48
- Specifications, Page 84
- STAND, Page 28
Side Stand., Page 28
- STEERING/WHEEL BEARINGS, Page 63
Inspecting the steering for free play,
Page 64
Steering Inspection., Page 63
Wheel Bearing inspection., Page 64
- SUSPENSION, Page 65, Page 66
Adjuster Location.
Front., Page 66
Rear., Page 66
Front Compression Damping
Adjustment., Page 67
Front Fork Inspection., Page 65
Front Rebound Damping Adjustment.,
Page 67
Front Spring Pre-load Adjustment.,
Page 67
Rear Compression Damping
Adjustment., Page 68
Rear Rebound Damping adjustment
(if fitted), Page 68
Rear Suspension Adjustment, Page
68
Suspension Setting, Page 65
- THROTTLE CONTROL, Page 54
- TIGHTENING TORQUES, Page 87
- TO START THE ENGINE, Page 34
- TO STOP THE ENGINE, Page 34
- TOOL KIT, Page 28
- TRANSMISSION, Page 85, Page 86
- TYRES, Page 86
- TYRES/WHEELS, Page 69
Minimum Recommended Tread Depth.,
Page 70
Tyre Inflation Pressures., Page 69
Tyre Markings., Page 69
Tyre Replacement., Page 71
Tyre Wear., Page 70
Wheel Markings., Page 69

Alphabetical Index

WARNING LABELS

Warning Label Locations., Page 11

Warning Labels., Page 10

WARNING LIGHTS, Page 21

Engine Management System
malfunction Indicator Light., Page
21

High Beam., Page 21

Indicators, Page 21

Low Fuel., Page 21

Neutral., Page 21

WARNINGS

Information., Page 2

Maintenance., Page 2

Owners handbook., Page 3

Warning labels, Page 2

Warning, caution and note., Page 1

WINDSCREEN, Page 63

Windscreen Cleaning., Page 63